

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIP DATE*
(Other instruction
reverse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM 013642

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL GAS WELL OTHER

2. NAME OF OPERATOR
Koch Exploration Company (Division of Koch Ind., Inc.)

3. ADDRESS OF OPERATOR
P.O. Box 2256; Wichita, Kansas 67201

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1775' FNL & 1550' FEL SW NE

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
GARDNER

9. WELL NO.
2

10. FIELD AND POOL, OR WILDCAT
Blanco Mesa Verde

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 31-32N-8W

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)
GR 6516' KB 6527'

12. COUNTY OR PARISH
San Juan

13. STATE
New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF
FRACTURE TREAT
SHOOT OR ACIDIZE
REPAIR WELL

PULL OR ALTER CASING
MULTIPLE COMPLETE
ABANDON*
CHANGE PLANS

WATER SHUT-OFF
FRACTURE TREATMENT
SHOOTING OR ACIDIZING
(Other) Completion

REPAIRING WELL
ALTERING CASING
ABANDONMENT*

(Other) Squeeze off perfs

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Kill well w/water.
2. Pull 1-1/2" & 2-3/8" tbg string & Baker "AD" pkr now set @ 5049'.
3. Set ret BP @ 3550' & spot two sx sand on top.
4. Set pkr @ 3300' & squeeze P.C. perfs 3433-3489 w/200 sx cmt.
5. Reset pkr @ 2900' & WOC 6 hrs; squeeze Fruitland perfs 3068-3110 w/200 sx cmt.
6. Drill out cmt. Test csg to 1000#.
7. Pull ret BP & run prod tbg.
8. Swab well in & blow dry.
9. Complete as Mesa Verde gas well only.



RECEIVED

SEP 26 1977

18. I hereby certify that the foregoing is true and correct

SIGNED Dwight L. Schmidt

TITLE Operations Manager

DATE 9-7-77

(This space for Federal or State office use)

APPROVED BY _____

TITLE _____

DATE _____

CONDITIONS OF APPROVAL, IF ANY: