

26. Trip in hole with a sawtooth collar and or bailer and clean out to P.B.T.D. and trip out of hole.

27. Trip in the hole with the production string (1/2 mule shoe on bottom and a seating nipple one joint off bottom), land tubing at 7339'. Nipple down B.O.P.'s, nipple up well head.

28. Swab well in and put well on production.

29. Rig down move off service unit.