CHOT FID WINTERACO O		
	Ĭ	
DISTRIBUTION	<u> </u>	<u> </u>
SANTA FE		
FILE		
U.S.G.S.		<u> </u>
LAND OFFICE	1_	<u> </u>
000000	1	ł

OIL CONSERVATION DIVISION

Form C-103

	P. O. BOX 2088	Revised 19-1-7
SANTA FE	SANTA FE, NEW MEXICO 87501	T
FILE		Sa. Indicate Type of Lease
U.S.G.S.		State Fee X
DERATOR		5. State Oil 6 Gas Lease No.
01 (447)		
	SUNDRY NOTICES AND REPORTS ON WELLS	
(00 NOT USE THIS	SUNDET INVITCES AND TO BEEFE OF PLUG BALL TO A DIFFERENT RESERVOIR. FORM FOR PROPOSALS TO DEFILE ON TO BEEFE OF PLUG BALL TO A DIFFERENT RESERVOIR. 156 "APPLICATION FOR PERMIT -" IFCOM C-1011 FOR SUCH PROPOSALS.)	
	11 27 C(C)	7. Unit Agreement Home
	AS OTHER-	Unknown
Name of Operator		8. Farm or Lease Name
James Hate	shor	Marjory M. Greer
Address of Operator	.net	9. Well No.
	Des 1641 Bloomfield, N.M.	Red Mountain # 6
Bloomfield (Dilfield Service Co. Box 1641 Bloomfield, N.M.	10. Field and Pool, or Wildcar
Location of Well		Menefee
UNIT LETTER	FEET FROM THE LINE AND FEET FROM	
	,	
THE	LINE, SECTION 29 TOWNSHIP 20N RANGE 9W HMPM.	
		12. County
	15. Elevation (Show whether DF, RT, GR, etc.)	
		McKinnley (\\\\\\\\\\
6.	Check Appropriate Box To Indicate Nature of Notice, Report or Oth	er Data
NC	TICE OF INTENTION TO: SUBSEQUENT	REPORT OF:
.,,		
PERFORM REMEDIAL WORK	PLUS AND ABANDON X REMEDIAL WORK	ALTERING CASING
	COMMENCE DRILLING DPMS.	PLUG AND ABANDONMENT
TEMPORARILY ASANDON	CHANGE PLANS CASING TEST AND CEMENT JOB	_
PULL OR ALTER CASING	OTHER	
OTHER		
7 Describe Proposed (r Completed Operations (Clearly state all pertinent details, and give pertinent dates, including	estimated date of starting any propose
work) SEE RULE 1	03.	
9-29-81 -	Moved Rig and equipment on location. Install we	ell head and
,	circulate. Cleaned out hole to 497, mixed and p	oumped 15 sacks
	class A cement, plug set from 497 to 375, pulled	
		l tubing back
	to 150 mixed and numbed 15 sacks class A cement	
	to 150, mixed and pumped 15 sacks class A cement	, plug set from
	150 to 30. Pulled tubing to 30. Mixed and pump	e, plug set from bed 10 sacks
		e, plug set from bed 10 sacks
	150 to 30. Pulled tubing to 30. Mixed and pump class A cement. Plug set from 30 feet to surface	e, plug set from bed 10 sacks ce.
9-30-81 -	150 to 30. Pulled tubing to 30. Mixed and pump	e, plug set from bed 10 sacks ce.
9-30-81 -	150 to 30. Pulled tubing to 30. Mixed and pump class A cement. Plug set from 30 feet to surface	e, plug set from bed 10 sacks ce.
	150 to 30. Pulled tubing to 30. Mixed and pump class A cement. Plug set from 30 feet to surface Rig down rig and equipment and moved off location	e, plug set from ped 10 sacks
	150 to 30. Pulled tubing to 30. Mixed and pump class A cement. Plug set from 30 feet to surface	e, plug set from ped 10 sacks
10-9-81 -	150 to 30. Pulled tubing to 30. Mixed and pump class A cement. Plug set from 30 feet to surface Rig down rig and equipment and moved off location Clean location leveled pits, and installed dry hand.	e, plug set from ped 10 sacks
10-9-81 -	150 to 30. Pulled tubing to 30. Mixed and pump class A cement. Plug set from 30 feet to surface Rig down rig and equipment and moved off location	e, plug set from ped 10 sacks
10-9-81 -	150 to 30. Pulled tubing to 30. Mixed and pump class A cement. Plug set from 30 feet to surface Rig down rig and equipment and moved off location Clean location leveled pits, and installed dry hand.	e, plug set from ped 10 sacks
10-9-81 -	150 to 30. Pulled tubing to 30. Mixed and pump class A cement. Plug set from 30 feet to surface Rig down rig and equipment and moved off location Clean location leveled pits, and installed dry hand.	e, plug set from ped 10 sacks
10-9-81 -	150 to 30. Pulled tubing to 30. Mixed and pump class A cement. Plug set from 30 feet to surface Rig down rig and equipment and moved off location Clean location leveled pits, and installed dry hand.	e, plug set from ped 10 sacks
10-9-81 -	150 to 30. Pulled tubing to 30. Mixed and pump class A cement. Plug set from 30 feet to surface Rig down rig and equipment and moved off location Clean location leveled pits, and installed dry hand.	e, plug set from ped 10 sacks
10-9-81 - 10-9-81 -	150 to 30. Pulled tubing to 30. Mixed and pump class A cement. Plug set from 30 feet to surface Rig down rig and equipment and moved off location Clean location leveled pits, and installed dry be Location ready for inspection.	e, plug set from bed 10 sacks
10-9-81 - 10-9-81 -	150 to 30. Pulled tubing to 30. Mixed and pump class A cement. Plug set from 30 feet to surface Rig down rig and equipment and moved off location Clean location leveled pits, and installed dry hand.	e, plug set from bed 10 sacks
10-9-81 - 10-9-81 -	150 to 30. Pulled tubing to 30. Mixed and pump class A cement. Plug set from 30 feet to surface Rig down rig and equipment and moved off location Clean location leveled pits, and installed dry be Location ready for inspection.	e, plug set from bed 10 sacks be. on. nole marker.
10-9-81 - 10-9-81 -	150 to 30. Pulled tubing to 30. Mixed and pump class A cement. Plug set from 30 feet to surface Rig down rig and equipment and moved off location Clean location leveled pits, and installed dry be Location ready for inspection.	e, plug set from bed 10 sacks ce.