

Douglas Kenaston
Masden - Selby #3
1080/N; 940/E
A-28-29N-11W
San Juan County

5. Presumed downhole equipment.

10 3/4" casing set at 89' with 10 sacks.
5 1/2" casing set at 571' with 25 sacks.
Total Depth 670'.

6. Commission - approved plugging program.

Set a 25 sack cement plug from 670 feet. Tag cement top after six hours. Cut and pull 5 1/2" casing from below 180' or perforate four holes in casing at 180' and cement inside and outside of the 5 1/2" casing from 180' to 80'.

Stabilize the 5 1/2" casing at the surface, if any, remove all junk, and level the location.

