

Hare & McCoy
H. L. Hare #2
B-23-29N-11W
150/N; 1980/E

1. Down hole Equipment
Unknown

Total Depth 802'

2. Plugging Program

Clean out hole to 802'

Set a cement plug from 802' to 650'

Cut and pull casing from below 150' or perforate casing at 150'
and set a cement plug from 150' to 50'

Set a cement plug at the surface, using 10 sacks of cement

Clean and level location

A marker will not be required