

TENTATIVE CEMENTING PROGRAMS

Bloomfield Oil & Gas Co.
Sheetz #1
M-14-29N-11W

Division-approved Plugging Program

Clean out hole to 700'

Set a cement plug 700-600' with ²⁵35 sacks of neat cement.

Set a cement plug 150'-50' with 30 sacks of neat cement.

Set a top plug with 10 sacks of neat cement. Leave top of cement at least 3' below ground level, as well as in a cultivated field.

Fill pits, clean & level location.

A dry hole marker will not be required.

All plugs will be a ^{NEAT}~~Class A, B or C~~ cement with or without CaCl₂