

TENTATIVE CEMENTING PROGRAMS

Union Oil & Mining
Carl Lanier #1
C-6-29N-3W

Division-approved Plugging Program

Clean out hole to 505'

Set a cement plug 505'-405' with neat cement

Set a cement plug 150'-50' with neat cement.

Set a top plug with 10 sacks of neat cement

A dry hole marker may or may not be required.

Fill pits, clean & level location

Hole is not cased

Hole size is unknown. Should take 50-60 sacks to plug.

There is also a possibility landowner may want to run a few joints of casing & convert it to a water well. Hole flows about 10 gal/min. of fresh water.

All Plugs will be a Class A,B or C cement with or without Cac12