

Phillips & Spence  
Martin #2  
N-34-30N-11W

Presumed Downhole Equipment

8 $\frac{1}{4}$ " casing at 80'  
6 5/8" casing at 615'  
5" casing at 720'  
Total depth 1220'  
Plugged Back to 1100'

Division-approved Plugging Program

1. Clean out hole to 1100'
2. Set a Cement plug 1100'-1000'
3. Set a cement plug 700'-600'
4. Set a cement plug 150'-50'
5. Set a top plug <sup>at 100'</sup> and erect marker
6. Fill & Level pit and clean Location if applicable

All plugs will be class A<sup>A</sup> or C cement with or without Cac12