

McCoy & Phillips  
Martin #1  
N-34-30N-11W

Presumed Downhole Equipment

10" casing at 20'  
6 5/8" casing at 738'  
5" casing at 942'  
Total Depth at 1320'  
Plugged Back to 1170'

Division-approved Plugging Program

1. Clean out hole to 1170'
2. Set a cement plug to 1170' to 1070'
3. Set a cement plug 700'-600'
4. Set a cement plug 150'-50'
5. Set a top plug, and erect marker
6. Fill & level pit & clean location if applicable

All plugs will be a Class A or C cement with or without CaCl<sub>2</sub>

1000 1000 1000  
1000 1000 1000  
1000 1000 1000

1000 1000 1000 1000 1000 1000

1000 1000 1000 1000  
1000 1000 1000 1000  
1000 1000 1000 1000  
1000 1000 1000 1000  
1000 1000 1000 1000

1000 1000 1000 1000 1000 1000

1000 1000 1000 1000 1000 1000

1000 1000 1000 1000 1000 1000

1000 1000 1000 1000 1000 1000

1000 1000 1000 1000 1000 1000

1000 1000 1000 1000 1000 1000

1000 1000 1000 1000 1000 1000

1000 1000 1000 1000 1000 1000