Submit 3 Copies To Appropriate District Office	State of New Mexico	Form C-103
District I Energy, 1625 N. French Dr., Hobbs, NM 88240	Minerals and Natural Resources	WELL API NO.
District II 1301 W. Grand Ave., Artesia, NM 88210 OIL CO	ONSERVATION DIVISION	30-025-25500
District III 12	220 South St. Francis Dr.	5. Indicate Type of Lease STATE FEE 7
1000 Rio Brazos Rd., Aztec, NM 87410 District IV	Santa Fe, NM 87505	6. State Oil & Gas Lease No.
1220 S. St. Francis Dr., Santa Fe, NM 87505		
SUNDRY NOTICES AND RE		7. Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH		H.T. Mattern NCT- (C)
PROPOSALS.) 1. Type of Well:		8. Well Number
Oil Well Gas Well Other		11
2. Name of Operator		9. OGRID Number
Chevron USA Inc 3. Address of Operator		10. Pool name or Wildcat
15 Smith Rd, Midland, TX	79705	Wildcat Paddock
4. Well Location		
Unit Letter M :410376 fee	t from the South line and 66	feet from the West line
Section 8 To	wnship 21-S Range 37-E	NMPM Lea County
	(Show whether DR, RKB, RT, GR, etc.	
Pit or Below-grade Tank Application (For pit or below-gra	de tank closures, a form C-144 must be attache	d)
Pit Location: UL M Sect 8 Twp 21S Rng 37E P		
Distance from nearest surface water Below-grad		
410 feet from the South line and 660 feet from	the West line (Steel Tank)	6 y
reet from the Octain line and Octo feet from	me (Steer rank)	
	Box to Indicate Nature of Notice, TO: SUB ABANDON REMEDIAL WOR	SEQUENT REPORT OF:
12. Check Appropriate I NOTICE OF INTENTION PERFORM REMEDIAL WORK ☐ PLUG AND A	Box to Indicate Nature of Notice, TO: SUB ABANDON	SEQUENT REPORT OF: K
12. Check Appropriate I NOTICE OF INTENTION PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PL PULL OR ALTER CASING MULTIPLE COMPLETIC	Box to Indicate Nature of Notice, TO: SUB ABANDON	SEQUENT REPORT OF: K
12. Check Appropriate INOTICE OF INTENTION OF PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PLULL OR ALTER CASING MULTIPLE COMPLETION OTHER:	Box to Indicate Nature of Notice, TO: SUB REMEDIAL WOR ANS COMMENCE DR CASING TEST A CEMENT JOB OTHER:	SEQUENT REPORT OF: K
12. Check Appropriate INOTICE OF INTENTION OF PERFORM REMEDIAL WORK PLUG AND ATTEMPORARILY ABANDON CHANGE PLULL OR ALTER CASING MULTIPLE COMPLETION OTHER: 13. Describe proposed or completed operation	Box to Indicate Nature of Notice, TO: SUB ABANDON	SEQUENT REPORT OF: K
12. Check Appropriate INOTICE OF INTENTION OF PERFORM REMEDIAL WORK PLUG AND ATTEMPORARILY ABANDON CHANGE PLULL OR ALTER CASING MULTIPLE COMPLETION OTHER: 13. Describe proposed or completed operation of starting any proposed work). SEE RUL	Box to Indicate Nature of Notice, TO: SUB ABANDON	SEQUENT REPORT OF: K ALTERING CASING D LLING OPNS PLUG AND ABANDONMENT ND D d give pertinent dates, including estimated date
12. Check Appropriate INOTICE OF INTENTION TO THE PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PLUL OR ALTER CASING MULTIPLE COMPLETIC OTHER: 13. Describe proposed or completed operation of starting any proposed work). SEE RUL or recompletion. 1. Notify OCD 24 hours Prior to MI & RU. 2. RIH set 5 1/2 CIBP at 5175 spot 25sx plug 5175 (3. Displace hole W/MLF, 9.5 # Brine with 25# gel P/I. 4. Spot 55sx plug 3600-3100 (Queen, DV-Tool). 5. Spot 40sx plug 2700-2400 (B-Salt, Yates) WOC T. 6. Spot 35sx plug 1400-1100 (8 5/8 Shoe, T-Salt) W. 7. Spot 40sx plug 250-Surf (Surf) Tag @ Surf I hereby certify that the information above is true as	Box to Indicate Nature of Notice, TO: SUB ABANDON	SEQUENT REPORT OF: K ALTERING CASING ALTERING
12. Check Appropriate INOTICE OF INTENTION TO PERFORM REMEDIAL WORK ☐ PLUG AND ATTEMPORARILY ABANDON ☐ CHANGE PLUG AND ATTEMPORARILY ABANDON ☐ CHANGE PLUG OF ALTER CASING ☐ MULTIPLE COMPLETION OF Starting any proposed or completed operation of starting any proposed work). SEE RULL or recompletion. 1. Notify OCD 24 hours Prior to MI & RU. 2. RIH set 5 1/2 CIBP at 5175 spot 25sx plug 5175 (3. Displace hole W/MLF, 9.5 # Brine with 25# gel P/I. 4. Spot 55sx plug 3600-3100 (Queen, DV-Tool). 5. Spot 40sx plug 2700-2400 (B-Salt, Yates) WOC TO Spot 35sx plug 1400-1100 (8 5/8 Shoe, T-Salt) W. 7. Spot 40sx plug 250-Surf (Surf) Tag @ Surf	Box to Indicate Nature of Notice, TO: SUB ABANDON	SEQUENT REPORT OF: K ALTERING CASING ALTERING
12. Check Appropriate INOTICE OF INTENTION TO THE PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PLUL OR ALTER CASING MULTIPLE COMPLETIC OTHER: 13. Describe proposed or completed operation of starting any proposed work). SEE RUL or recompletion. 1. Notify OCD 24 hours Prior to MI & RU. 2. RIH set 5 1/2 CIBP at 5175 spot 25sx plug 5175 (3. Displace hole W/MLF, 9.5 # Brine with 25# gel P/I. 4. Spot 55sx plug 3600-3100 (Queen, DV-Tool). 5. Spot 40sx plug 2700-2400 (B-Salt, Yates) WOC T. 6. Spot 35sx plug 1400-1100 (8 5/8 Shoe, T-Salt) W. 7. Spot 40sx plug 250-Surf (Surf) Tag @ Surf I hereby certify that the information above is true as	Box to Indicate Nature of Notice, TO: SUB ABANDON	SEQUENT REPORT OF: K ALTERING CASING ALTERING
12. Check Appropriate INOTICE OF INTENTION PERFORM REMEDIAL WORK □ PLUG AND A TEMPORARILY ABANDON □ CHANGE PL PULL OR ALTER CASING □ MULTIPLE COMPLETION OTHER: 13. Describe proposed or completed operation of starting any proposed work). SEE RULL or recompletion. 1. Notify OCD 24 hours Prior to MI & RU. 2. RIH set 5 1/2 CIBP at 5175 spot 25sx plug 5175 (3). Displace hole W/MLF, 9.5 # Brine with 25# gel P/I. 4. Spot 55sx plug 3600-3100 (Queen, DV-Tool). 5. Spot 40sx plug 2700-2400 (B-Salt, Yates) WOCT 6. Spot 35sx plug 1400-1100 (8 5/8 Shoe, T-Salt) W. 7. Spot 40sx plug 250-Surf (Surf) Tag @ Surf I hereby certify that the information above is true at grade tank has been/will be constructed or closed according to the surface of the surfa	Box to Indicate Nature of Notice, TO: SUB REMEDIAL WOR ANS COMMENCE DR CASING TEST A CEMENT JOB OTHER: S. (Clearly state all pertinent details, an E 1103. For Multiple Completions: At Paddock) WOC Tag 4935 BBL. Tag 2318. OC Tag 1090. Ind complete to the best of my knowledge to NMOCD guidelines	SEQUENT REPORT OF: K ALTERING CASING ALTERING
12. Check Appropriate INOTICE OF INTENTION PERFORM REMEDIAL WORK □ PLUG AND A TEMPORARILY ABANDON □ CHANGE PL PULL OR ALTER CASING □ MULTIPLE COMPLETION OTHER: 13. Describe proposed or completed operation of starting any proposed work). SEE RUL or recompletion. 1. Notify OCD 24 hours Prior to MI & RU. 2. RIH set 5 1/2 CIBP at 5175 spot 25sx plug 5175 (3. Displace hole W/MLF, 9.5 # Brine with 25# gel P/I. 4. Spot 55sx plug 3600-3100 (Queen, DV-Tool). 5. Spot 40sx plug 2700-2400 (B-Salt, Yates) WOC T. 6. Spot 35sx plug 1400-1100 (8 5/8 Shoe, T-Salt) W. 7. Spot 40sx plug 250-Surf (Surf) Tag @ Surf I hereby certify that the information above is true at grade tank has been/will be constructed or closed according to the structure of the	Box to Indicate Nature of Notice, TO: SUB REMEDIAL WOR ABANDON COMMENCE DR CASING TEST A CEMENT JOB OTHER: S. (Clearly state all pertinent details, an E 1103. For Multiple Completions: At Paddock) WOC Tag 4935 BBL. Tag 2318. OC Tag 1090. Ind complete to the best of my knowledg to NMOCD guidelines , a general permit TITLE Consultan E-mail address:	SEQUENT REPORT OF: K ALTERING CASING ALTERING ALTERING CASING ALTERING ALTERING CASING ALTERING ALTERING CASING ALTERING CASI
12. Check Appropriate INOTICE OF INTENTION PERFORM REMEDIAL WORK □ PLUG AND A TEMPORARILY ABANDON □ CHANGE PL PULL OR ALTER CASING □ MULTIPLE COMPLETION OTHER: 13. Describe proposed or completed operation of starting any proposed work). SEE RULTOR or recompletion. 1. Notify OCD 24 hours Prior to MI & RU. 2. RIH set 5 1/2 CIBP at 5175 spot 25sx plug 5175 (3. Displace hole W/MLF, 9.5 # Brine with 25# gel P/I. 4. Spot 55sx plug 3600-3100 (Queen, DV-Tool). 5. Spot 40sx plug 2700-2400 (B-Salt, Yates) WOC TOOLS. 6. Spot 35sx plug 1400-1100 (8 5/8 Shoe, T-Salt) W. 7. Spot 40sx plug 250-Surf (Surf) Tag @ Surf I hereby certify that the information above is true at grade tank has been/will be constructed or closed according to SIGNATURE Type or print name	Box to Indicate Nature of Notice, TO: SUB ABANDON	SEQUENT REPORT OF: K ALTERING CASING ALTERING ALTERING CASING ALTERING ALTERING CASING ALTERING ALTERING CASING ALTERING CASI

Approved as to plugging of the Well Bore Liability under bond is retained until surface restoration is completed.