
OCD-HOBBS Form 3160-5 UNITED STATES (August 1999) CELVED EPARTMENT OF THE INTERIOR FORM APPROVED OMB NO. 1004-0135 FEB 1 0 2009 BUREAU OF LAND MANAGEMENT Expires: November 30, 2000 5. Lease Serial No. SUNDRY NOTICES AND REPORTS ON WELLS LC-031736(B) NM HOBBS Quality this form for proposals to drill or to re-enter an 6. If Indian, Allottee or Tribe Name abandoned well. Use Form 3160-3 (APD) for such proposals. 7. If Unit or CA/Agreement, Name and/or No. SUBMIT IN TRIPLICATE - Other instructions on reverse side 1. Type of Well Oil Well X Gas Well 8. Well Name and No. Gillully B Federal #20 2. Name of Operator RA A Occidental Permian Limited Partnership 157984 9. API Well No. 3a. Address 3b. Phone No. (include area code) 30-025-25937 P.O. Box 50250, Midland, TX 79710-0250 432-685-5717 10. Field and Pool, or Exploratory Area 4. Location of Well (Footage, Sec., T., R., M., or Survey Description) Eumont Yates-SR-On ~ 1930 FNL 760 FEL SENE(H) Sec 21 T20S R37E 11. County or Parish, State CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA 12. TYPE OF SUBMISSION TYPE OF ACTION Notice of Intent Acidize Deepen Production (Start/Resume) Water Shut-Off Alter Casing Fracture Treat Reclamation Well Integrity X Subsequent Report Casing Repair New Construction Other TA Status Recomplete Change Plans Plug and Abandon Temporarily Abandon Final Abandonment Notice Convert to Injection Plug Back Water Disposal Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the final site is ready for final inspection.) RUPU, NDWH, NUBOP, REL & POOH w/ tbg & pkr. RIH w/ tbg & bit, tag @ 3391', RU swab and swab all water. RIH & set CIBP @ 2852', POOH w/ tbg, Pressure casing to 500#, Circ w/ pkr fluid, NDBOP, NUWH, RDPU, TA Well. After 4-3-09 the well must be online No Notice of Intent was filed prior to TA of well. Last production report on record was or plans to P & A must be submitted. 7/2007 need to catch up on production reports. BLM not called to witness MIT. Supply justification for well to be TA. SEE ATTACHED FOR CONDITIONS OF APPROVAL I hereby certify that the foregoing is true and correct Title Name (Printed/Typed) David Stewart Sr. Regulatory Analyst

Title 18 U.S.C. Section 1001, and Title 43 U.S.C. Section 1212, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.



Gillar Broken A & Tom A & Tom & State of the Stark man. gressent: tes

BUREAU OF LAND MANAGEMENT Carlsbad Field Office 620 East Greene Street Carlsbad, New Mexico 88220 575-234-5972

Temporary Abandonment of Wells on Federal Lands Conditions of Approval

A temporarily abandoned well is defined as a completion that is not capable of production in paying quantities but which may have value as a service well. Pursuant to 43 CFR 3162.3-4 (c), no well may be temporarily abandoned for more than 30 days without the prior approval of the authorized officer.

Temporary Abandonment (TA) status approval requires a successful mechanical or casing integrity test as follows:

- 1. A Notice of Intent (NOI) Sundry Notice (Form 3160-5) requesting approval to run a mechanical integrity test (MIT) or casing integrity test (CIT).
- 2. A description of the temporary abandonment procedure.
 - a. A bridge plug or packer must be installed as close to 50 feet above any open perforations or open hole as possible. If a cement plug is used, the top of the cement must be verified by tagging.
 - b. The wellbore must be filled with corrosion inhibited fluid and pressure tested to 500 psi. The casing shall be capable of holding this pressure for at least 30 minutes with a 10% allowable leakoff.
 - c. All downhole production/injection equipment (tubing, rods, etc.) shall be removed from the casing if they are not isolated by a packer.
 - d. A bradenhead test must be conducted. If the test indicates a problem exists, a remedial plan and time frame for remediation shall be submitted within ninety (90) days of the test.
 - e. Contact the appropriate BLM office at least 24 hours prior to the scheduled Casing Integrity Test. For wells in Eddy County, 575-361-2822; Lea County 575-393-3612.
- Provides justification why the well should be temporarily abandoned rather than permanently
 plugged and abandoned and an estimated date that the well will be returned to beneficial use or
 plugged and abandoned.

Wells that successfully pass the casing integrity test may be approved for Temporary Abandonment (TA) status provided that the operator:

- 1. Submits a subsequent Sundry Notice (Form 3160-5) requesting TA approval.
- 2. Describes the temporary abandonment procedure.
- 3. Attaches a clear copy or the original of the pressure test chart.

If the well does not pass the casing integrity test, then the operator shall within 30 days submit to BLM for approval one of the following:

- 1. A procedure to repair the casing so that a TA approval can be granted.
- 2. A procedure to plug and abandon the well.

Submit Subsequent Report and well bore diagram with all Perforations and CIBP with tops of cement. Well will be approved after successful MIT and subsequent report is submitted. Submit Plans to recomplete, produce or P&A by April 3, 2009 Gillully B Federal #20