## State of New Mexico Energy, Minerals and Natural Resources Department

J

Form C-103 Revised 5-27-2004

| FILE IN TRIPLICATE OIL CONSERVATION DIVISION   |  |
|--|--|
| DISTRICT I 1625 N. French Dr., Hobbs, NM 88240  DISTRICT I Santa Fe NM 87505   | WELL API NO.<br>30/025-24005   |
| Santa Fe, NM 87505   | 5. Indicate Type of Lease  |
| 1301 W. Grand Ave. Artesia. NM 88210   | STATE X FEE  |
| DISTRICT III HOBBSOCD  | 6. State Oil & Gas Lease No  |
| 1000 Rio Brazos Rd, Aztec, NM 87410  |  |
| SUNDRY NOTICES AND REPORTS ON WELLS  | 7. Lease Name or Unit Agreement Name   |
| (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR USE "APPLICATION FOR PERMIT" (Form C-101) for such proposals.)   | Conoco State   |
| 1. Type of Well.   | 8. Well No. 4  |
| Oil Well X , Gas Well Other  | ,  |
| 2. Name of Operator OXY USA, Inc.  | 9. OGRID No. 148967  |
| 3 Address of Operator  | 10. Pool name or Wildcat   |
| HCR 1 Box 90 Denver City, TX 79323   | Hobbs Drinkard   |
| 4 Well Location  |  |
| Unit Letter O : 688 Feet From The South 2111 Fee   | t From The East Line   |
| Section 33 Township 18-S Range 38-E  | NMPM Lea County  |
| The Location (Stort Medical Property of Control Property of Contro |  |
| Pit or Below-grade Tank Application or Closure   |  |
| Pit Type Depth of Ground Water Distance from nearest fresh water well Distance from nearest surface water  |  |
| Pit Liner Thickness mil Below-Grade Tank: Volume bbls; Construction Ma   |  |
|  |  |
| 12. Check Appropriate Box to Indicate Nature of Notice, Report, or C   | Other Data   |
| NOTICE OF INTENTION TO: SUBS   | SEQUENT REPORT OF:   |
|  | SEQUENT REPORT OF:  ALTERING CASING  |
| PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK   | ALTERING CASING  |
| PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPI  | ALTERING CASING  NS. PLUG & ABANDONMENT  |
| PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPI PULL OR ALTER CASING Multiple Completion CASING TEST AND CEMEN   | ALTERING CASING  NS. PLUG & ABANDONMENT  IT JOB  |
| PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK  TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPI PULL OR ALTER CASING Multiple Completion CASING TEST AND CEMEN  OTHER Tempor  | ALTERING CASING  NS. PLUG & ABANDONMENT  IT JOB Arily Abandon well  X  |
| PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPE PULL OR ALTER CASING Multiple Completion CASING TEST AND CEMENT OTHER Tempore  13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed of RUPU & RU. ND wellhead/NU BOP.  2. POOH w/plunger lift equipment.  3. RIH w/ bit. Tag @6597'. Circulate well. POOH w/bit.   | ALTERING CASING  NS. PLUG & ABANDONMENT  IT JOB X  arily Abandon well X  , including estimated date of starting any  |
| PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK  TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPE  PULL OR ALTER CASING Multiple Completion CASING TEST AND CEMENT  OTHER Tempor  13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed of RUPU & RU. ND wellhead/NU BOP.  2. POOH w/plunger lift equipment.  3. RIH w/ bit. Tag @6597'. Circulate well. POOH w/bit.  4. RIH w/CIBP set @6300'. POOH w/tubing.   | ALTERING CASING  NS. PLUG & ABANDONMENT  IT JOB X  arily Abandon well X  , including estimated date of starting any  |
| PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK  TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPE  PULL OR ALTER CASING Multiple Completion CASING TEST AND CEMENT  OTHER Tempor  13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed of RUPU & RU. ND wellhead/NU BOP.  2. POOH w/plunger lift equipment.  3. RIH w/ bit. Tag @6597'. Circulate well. POOH w/bit.  4. RIH w/CIBP set @6300'. POOH w/tubing.  5. RIH w/CIBP set @5800'. Dump bail 25 ft of cement on top of CIBP.  | ALTERING CASING  NS. PLUG & ABANDONMENT  ST JOB X  arily Abandon well X  , including estimated date of starting any completion or recompletion.  |
| PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK  TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPE  PULL OR ALTER CASING Multiple Completion CASING TEST AND CEMENT  OTHER Tempor  13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed of RUPU & RU. ND wellhead/NU BOP.  2. POOH w/plunger lift equipment.  3. RIH w/ bit. Tag @6597'. Circulate well. POOH w/bit.  4. RIH w/CIBP set @6300'. POOH w/tubing.   | ALTERING CASING  NS. PLUG & ABANDONMENT  ST JOB X  arily Abandon well X  , including estimated date of starting any completion or recompletion.  |
| PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK  TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPE  PULL OR ALTER CASING Multiple Completion CASING TEST AND CEMEN  OTHER Tempor.  13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed of RUPU & RU. ND wellhead/NU BOP.  2. POOH w/plunger lift equipment.  3. RIH w/bit. Tag @6597'. Circulate well. POOH w/bit.  4. RIH w/CIBP set @6300'. POOH w/tubing.  5. RIH w/CIBP set @5800'. Dump bail 25 ft of cement on top of CIBP.  6. Test casing to 520 PSI for 30 minutes and chart for the NMOCD. Robert Harrison w/NMOCD on RDPU & RU.  8. Well is temporarily abandoned  | ALTERING CASING  NS. PLUG & ABANDONMENT  IT JOB X  arily Abandon well X  , including estimated date of starting any completion or recompletion.  |
| PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK  TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPE  PULL OR ALTER CASING Multiple Completion CASING TEST AND CEMEN  OTHER Tempor.  13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed of RUPU & RU. ND wellhead/NU BOP.  2. POOH w/plunger lift equipment.  3. RIH w/bit. Tag @6597'. Circulate well. POOH w/bit.  4. RIH w/CIBP set @6300'. POOH w/tubing.  5. RIH w/CIBP set @5800'. Dump bail 25 ft of cement on top of CIBP.  6. Test casing to 520 PSI for 30 minutes and chart for the NMOCD. Robert Harrison w/NMOCD on RDPU & RU.  8. Well is temporarily abandoned  | ALTERING CASING  NS. PLUG & ABANDONMENT  IT JOB X  arily Abandon well X  , including estimated date of starting any completion or recompletion.  |
| PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK  TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPE  PULL OR ALTER CASING Multiple Completion CASING TEST AND CEMEN  OTHER Tempor.  13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed of RUPU & RU. ND wellhead/NU BOP.  2. POOH w/plunger lift equipment.  3. RIH w/bit. Tag @6597'. Circulate well. POOH w/bit.  4. RIH w/CIBP set @6300'. POOH w/tubing.  5. RIH w/CIBP set @5800'. Dump bail 25 ft of cement on top of CIBP.  6. Test casing to 520 PSI for 30 minutes and chart for the NMOCD. Robert Harrison w/NMOCD on RDPU & RU.  8. Well is temporarily abandoned  | ALTERING CASING  NS. PLUG & ABANDONMENT  ST JOB X  arily Abandon well X  , including estimated date of starting any completion or recompletion.  |
| PERFORM REMEDIAL WORK PLUG AND ABANDON CHANGE PLANS COMMENCE DRILLING OPPOSED PRODUCTION OF THE Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed of RUPU & RU. ND wellhead/NU BOP.  2. POOH w/plunger lift equipment.  3. RIH w/bit. Tag @6597'. Circulate well. POOH w/bit.  4. RIH w/CIBP set @6300'. POOH w/tubing.  5. RIH w/CIBP set @5800'. Dump bail 25 ft of cement on top of CIBP.  6. Test casing to 520 PSI for 30 minutes and chart for the NMOCD. Robert Harrison w/NMOCD of RDPU & RU.  8. Well is temporarily abandoned.  RUPU 06/16/09 RDPU 06/25/09  | ALTERING CASING  PLUG & ABANDONMENT  IT JOB  arily Abandon well  x  n including estimated date of starting any completion or recompletion.   |
| PERFORM REMEDIAL WORK PLUG AND ABANDON COMMENCE DRILLING OPEN PULL OR ALTER CASING Multiple Completion CASING TEST AND CEMEN OTHER Tempor.  13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed of RUPU & RU. ND wellhead/NU BOP.  2. POOH w/plunger lift equipment.  3. RIH w/bit. Tag @6597'. Circulate well. POOH w/bit.  4. RIH w/CIBP set @6300'. POOH w/tubing.  5. RIH w/CIBP set @6300'. Dump bail 25 ft of cement on top of CIBP.  6. Test casing to 520 PSI for 30 minutes and chart for the NMOCD. Robert Harrison w/NMOCD or 7. RDPU & RU.  8. Well is temporarily abandoned.  RUPU 06/16/09 RDPU 06/25/09  Thereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify   | ALTERING CASING  PLUG & ABANDONMENT  IT JOB  arily Abandon well  x  n including estimated date of starting any completion or recompletion.   |
| PERFORM REMEDIAL WORK  TEMPORARILY ABANDON  CHANGE PLANS  COMMENCE DRILLING OPPORT OF THE PULL OR ALTER CASING  Multiple Completion  OTHER  Temport  13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates proposed work) SEE  RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed of RUPU & RU. ND wellhead/NU BOP.  POOH w/plunger lift equipment.  RIH w/bit. Tag @6597'. Circulate well. POOH w/bit.  RIH w/CIBP set @6300'. POOH w/tubing.  RIH w/CIBP set @5800'. Dump bail 25 ft of cement on top of CIBP.  Test casing to 520 PSI for 30 minutes and chart for the NMOCD. Robert Harrison w/NMOCD of RDPU & RU.  Well is temporarily abandoned.  RUPU 06/16/09  RDPU 06/25/09  Thereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify constructed or closed according to NMOCD guidelines  Remedial work  COMMENCE DRILLING OPPORTMENT OF THE COMMENCE DRILLING OPPORTMENT OF THE CASING TEST AND CEMENT  COMMENCE DRILLING OPPORTMENT OF THE CASING TEST AND CEMENT  CASING TEST AND CEMENT  CASING TEST AND CEMENT  OTHER  Temport  Temport  Temport  This Approval of Temport  Abandoriment Expires  This Approval of Temport  Abandoriment Expires  Thereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify constructed or closed according to NMOCD guidelines  RUPU of a green and complete to the best of my knowledge and belief. I further certify constructed or closed according to NMOCD guidelines  REMEDIAL COMMENCE DRILLING OPPORTMENT  REMEDIAL COMMENCE DRILLING OPPORTMENT  CASING TEST AND CEMENT  CASING | ALTERING CASING  PLUG & ABANDONMENT  IT JOB  arily Abandon well  x  n including estimated date of starting any completion or recompletion.  The site for test is a site for test.  porary 9-25-2014  that any pit or below-grade tank has been/will be   |
| PERFORM REMEDIAL WORK PLUG AND ABANDON CHANGE PLANS COMMENCE DRILLING OPPOSED PROPERTY OF THE  | ALTERING CASING  PLUG & ABANDONMENT  Arrily Abandon well  It is, including estimated date of starting any completion or recompletion.  In site for test.  POTATY 9-25-2014  That any pit or below-grade tank has been/will be the OCD-approved   |
| PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPI PULL OR ALTER CASING Multiple Completion CASING-TEST AND CEMEN OTHER Tempor  13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed of RUPU & RU. ND wellhead/NU BOP. 2. POOH w/plunger lift equipment. 3. RIH w/bit. Tag @6597'. Circulate well. POOH w/bit. 4. RIH w/CIBP set @6300'. POOH w/tubing. 5. RIH w/CIBP set @5800'. Dump bail 25 ft of cement on top of CIBP. 6. Test casing to 520 PSI for 30 minutes and chart for the NMOCD. Robert Harrison w/NMOCD of 7. RDPU & RU. 8. Well is temporarily abandoned. RUPU 06/16/09 RDPU 06/25/09  Thereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify constructed or closed according to NMOCD guidelines , a general permit or an (attached) alternative plan  | ALTERING CASING  PLUG & ABANDONMENT  Arily Abandon well  An including estimated date of starting any completion or recompletion.  The site for test is a site for test in the sit |
| PERFORM REMEDIAL WORK PLUG AND ABANDON COMMENCE DRILLING OPICE  PULL OR ALTER CASING Multiple Completion CASING TEST AND CEMENT  OTHER Tempor  13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed of RUPU & RU. ND wellhead/NU BOP.  2. POOH w/plunger lift equipment.  3. RIH w/bit. Tag @6597'. Circulate well. POOH w/bit.  4. RIH w/CIBP set @6300'. POOH w/tubing.  5. RIH w/CIBP set @65800'. Dump bail 25 ft of cement on top of CIBP.  6. Test casing to 520 PSI for 30 minutes and chart for the NMOCD. Robert Harrison w/NMOCD of RDPU & RU.  8. Well is temporarily abandoned.  RUPU 06/16/09  RDPU 06/25/09  This Approval of Temporarily abandoned according to NMOCD guidelines and complete to the best of my knowledge and belief. I further certify constructed or closed according to NMOCD guidelines are general permit or an (attached) alternative plan  SIGNATURE TITLE Administrative mendy johnson@oxy.com  | ALTERING CASING  NS. PLUG & ABANDONMENT  ST JOB TAIL TOTAL T |
| PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPI PULL OR ALTER CASING Multiple Completion CASING TEST AND CEMEN OTHER Tempor.  13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed of RUPU & RU. ND wellhead/NU BOP. 2. POOH w/plunger lift equipment. 3. RIH w/bit. Tag @6597'. Circulate well. POOH w/bit. 4. RIH w/CIBP set @6300'. POOH w/tubing. 5. RIH w/CIBP set @5800'. Dump bail 25 ft of cement on top of CIBP. 6. Test casing to 520 PSI for 30 minutes and chart for the NMOCD. Robert Harrison w/NMOCD of RDPU & RU. 8. Well is temporarily abandoned.  RUPU 06/16/09 RDPU 06/25/09  This Approval of Temporarily details and complete to the best of my knowledge and belief. I further certify constructed or closed according to NMOCD guidelines a general permit or an (attached) alternative plan  SIGNATURE Mendy A. Johnson E-mail address: mendy johnson@oxy.com   | ALTERING CASING  PLUG & ABANDONMENT  Arily Abandon well  An including estimated date of starting any completion or recompletion.  The site for test is a site for test in the sit |

