

COPIES RECEIVED		
TRIBUTION		
FE		
S.		
D OFFICE		
RATOR		

NEW MEXICO OIL CONSERVATION COMMISSION  
 JUN 13 9 10 AM '66

Form C-103  
 Supersedes Old  
 C-102 and C-103  
 Effective 1-1-65

5a. Indicate Type of Lease  
 State  Fee

5. State Oil & Gas Lease No.  
**K-8876**

7. Unit Agreement Name  
 -

8. Farm or Lease Name  
**New Mexico State "AA"**

9. Well No.  
**1**

10. Field and Pool, or Wildcat  
**Allison Penn**

12. County  
**Roosevelt**

**SUNDRY NOTICES AND REPORTS ON WELLS**  
 (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
 USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL  GAS WELL  OTHER-

2. Name of Operator  
**Sunray DX Oil Company**

3. Address of Operator  
**P. O. Box 1416, Roswell, New Mexico**

4. Location of Well  
 UNIT LETTER **H** **1980** FEET FROM THE **North** LINE AND **660** FEET FROM  
 THE **East** LINE, SECTION **36** TOWNSHIP **8S** RANGE **36E** NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)  
**4066 DF**

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

**P&A as follows:**

1. Load hole with mud. Place 25 sx cmt plug over perfs at 9652-9668 from PBTB at 9703' to 9400'.
2. Pulled 4508' of 4 1/2" casing.
3. Placed 25 sx cmt plug at 4600'-4400' in 4 1/2" casing.
4. Pulled 318' of 8 5/8" casing.
5. Placed 60 sx cmt plug from 360'-260' in 13 3/8" casing.
6. Placed 10 sx cmt from top plug.
7. Cut off casing at ground level, install dry hole marker and cleared location of junk.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED B. F. Brawley TITLE District Engineer DATE 6-10-66

APPROVED BY [Signature] TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: