

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State  Fee

5. State Oil & Gas Lease No.  
L-523

**SUNDRY NOTICES AND REPORTS ON WELLS**  
DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Coastal States Gas Producing Company	8. Farm or Lease Name State "34"
3. Address of Operator P. O. Box 235, Midland, Texas 79701	9. Well No. 1
4. Location of Well UNIT LETTER <u>II</u> , 1980 FEET FROM THE <u>North</u> LINE AND <u>710</u> FEET FROM THE <u>East</u> LINE, SECTION <u>34</u> TOWNSHIP <u>14-S</u> RANGE <u>22-E</u> NMPM.	10. Field and Pool, or Wildcat Talk (Penn)
15. Elevation (Show whether DF, RT, GR, etc.) 4283' G	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set CIBP @ 9700' and dump 10' emb. on top of plug.
2. Set 25 sxs plug @ 5-1/2" casing stub.
3. Set 25 sxs plug @ 5440' (top of Gloria).
4. Set 50 sxs plug in and out @ 8-5/8" casing shoe @ 4910' (4115-3985).
5. Set 25 sxs plug @ top of salt @ proposed (1485').
6. Set 25 sxs plug @ 8-5/8" stub.
7. Set 25 sxs plug @ 396-330' in and out @ 13-3/8" shoe @ 300'.
8. Set 10 sxs plug in top.
9. Install DHM.
10. Clean up location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Joe P. Howard TITLE Division Production Manager DATE 1/31/77

APPROVED BY [Signature] SUPERVISOR DISTRICT [Signature] DATE 1/31/77

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

FEB 9 1972

OIL CONSERVATION COMM.  
HOBBS, N. M.