

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-85

53. Indicate Type of Lease
State Fee
5. State Oil & Gas Lease No.
E-3072-3

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR
USE APPLICATION FOR PERMIT FORM C-101 FOR SUCH PROPOSALS.

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER temp. shut-in	7. Unit Agreement Name
2. Name of Operator Conoco Inc.	8. Form or Lease Name East EK Unit
3. Address of Operator P.O. Box 460, Hobbs, NM 88240	9. Well No. 2
4. Location of Well UNIT LETTER J 1980 FEET FROM THE South LINE AND 1980 FEET FROM THE East LINE, SECTION 22 TOWNSHIP 18S RANGE 34E N.M.P.M.	10. Field and Pool, or Wildcat EK Queen East
15. Elevation (Show whether DF, RT, GR, etc.)	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIATION WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE OR CEASE OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. MIRU, spot 5 sx (48' ±) cement from 4461' - 4413'.
2. Pressure test casing to 600 psi for 15 min.
3. Spota 100' cement plug from 2075' - 1975' (104 sx ±), spot a 100' cement plug from 481' - 381', WOC 1/2 - 1 hr.
4. Tag top of cement. If cement top is below 381', fill 5-1/2" casing up to 381' with cement as necessary.
5. Spot a 100' cement plug from 100' - 0' (10.4 sx ±), cut casing 3" below restored ground level.
6. Erect a permanent steel P + A marker
7. Clean location, rig down.
8. A P & A sketch is attached.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *Jerry Sexton* TITLE Administrative Supervisor DATE 8-6-86

APPROVED BY DISTRICT I SUPERVISOR TITLE _____ DATE AUG 11 1986