

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

N.M. OIL CONS. COMMISSION
P.O. BOX 1980
MORRIS, NEW MEXICO 88240

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well
☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

3. Address and Telephone No.

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

5. Lease Designation and Serial No.

NM-077002

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

Nellis Federal

8. Well Name and No.

8

9. API Well No.

30-025-31691

10. Field and Pool, or Exploratory Area

Buffalo Yates

11. County or Parish, State

Lea, NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☐ Notice of Intent
☐ Subsequent Report
☒ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

10-24-95

MISU. Dig out cellar. Checked casing valves & nipples. RUSU.

10-25-95

Nipple Down tree and nipple up BOP's. Unset packer and pull out of hole. Ran 4 3/4" bit and 5 1/2" casing scraper and tubing to 3600'. Pull assembly out of hole. Ran CIBP and set at 3550'. Test to 550 PSI, OK. Displace hole with 10# Brine and cement with 2.5 sx. Top of cement 3430'. Displace hole with 12.5 lb/gal mud and lay down tubing to 510'. Pump cement to surface and lay down tubing. Top off cement.

10-26-95

Nipple down BOP's. Cut off wellhead and install dry hole marker. RDSU and cover cellar.

14. I hereby certify that the foregoing is true and correct

Signed

M.K. Estes

Title

Senior Administrative Analyst Date 11-14-95

(This space for Federal or State office use)

Approved by

Orig. Signed by Adam Salamah

Title

Date

12/15/95

Conditions of approval, if any: