

## THE USE OF SELF CONTAINED BREATHING EQUIPMENT

3. Respirators should be worn when:
  - A. Any employee working near the top or on top of any tank, unless a test reveals less than 10 ppm of H<sub>2</sub>S.
  - B. When breaking out any line where H<sub>2</sub>S can reasonable be expected.
  - C. When sampling air in areas to determine if toxic concentrations of H<sub>2</sub>S exist.
  - D. When working in areas where over 10 ppm of H<sub>2</sub>S has been detected.
  - E. At any time when there is a doubt as to the H<sub>2</sub>S level in the are to be entered.