

6. Trip out of the hole with the drilling assembly. Set a wireline retrievable bridge plug for 5-1/2", 17 #/ft casing at +/- 6500'. Test the plug to 1000 psi.
7. Lay down the drill pipe.
8. Nipple down the BOP stack. Install a manual 3000 psig BOP equipped with blind rams and 2-7/8" pipe rams. Release the rig. Rig down and move out rotary tools.