

Submit 1 Copy To Appropriate District
Office

District I – (575) 393-6161

1625 N. French Dr., Hobbs, NM 88240

District II – (575) 748-1283

811 S. First St., Artesia, NM 88210

District III – (505) 334-6178

1000 Rio Brazos Rd., Aztec, NM 87410

District IV – (505) 476-3460

1220 S. St. Francis Dr., Santa Fe, NM
87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

Form C-103

Revised August 1, 2011

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		WELL API NO. 30-025-01271
1. Type of Well: Oil Well Gas Well Other SWD		5. Indicate Type of Lease STATE X FEE
2. Name of Operator TLT SWD, Inc		6. State Oil & Gas Lease No.
3. Address of Operator PO Box 1906, Hobbs, NM 88241		7. Lease Name or Unit Agreement Name Phillips State
4. Well Location Unit Letter <u>I</u> : <u>1980</u> feet from the <u>South</u> line and <u>660</u> feet from the <u>East</u> line Section <u>25</u> Township <u>16S</u> Range <u>33E</u> NMPM Lea County		8. Well Number 001
11. Elevation (Show whether DR, RKB, RT, GR, etc.)		9. OGRID Number 287481
10. Pool name or Wildcat Kemnitz; Lower Wolfcamp		

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ **PLUG AND ABANDON** ☒ XX
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
DOWNHOLE COMMINGLE ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ P AND A
CASING/CEMENT JOB ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

SEE ATTACHED

See attached conditions of approval

4" diameter 4' tall above ground marker

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE [Signature] TITLE Agent DATE 6.6.2022
Type or print name N.Y. Merchant E-mail address: nymarch@permcoil.com PHONE: (575) 492-1236
For State Use Only

APPROVED BY: Kerry Fortner TITLE Compliance Officer A DATE 6/17/22
Conditions of Appro

Proposed Plugging Procedures

1. Install BOP, release packer and POOH with tubing.
2. Set 5 ½" CIPB at 10672'. Tag CIBP with tubing and circulate MLF. Spot 25 sx Class H cement on top of CIBP.
3. Spot 25 sx cement at 9600'.
4. Perforate at 7197' and squeeze with 40 sx cement. WOC and tag.
5. Cut casing 4593' and lay down.
6. Spot 75 sx cement at 4643'. WOC and tag. Stub plug and intermediate shoe.
7. Spot 40 sx at 2750'. Base salt.
8. Spot 40 sx at 1516'. Top salt.
9. Circulate cement to surface from 414'.

Well Sketch Present -
(Prior to P2A)

June 6, 2022

Phillips State # 1

API 30-025-01271


1980 FSL X 660 FEL

Unit Letter I, Section 25, T16S, R33E

Lea County, New Mexico

Spud 6/18/1957

After Conversion to SWD



www.pwllc.net

Phillips State #1

API # 30.025-01271

E. Sec 25 - T12S - R 33E

Proposed
Atty Plugging

6/6/2022

Lea Court, NM

mym

13³/₈ 48" 354'

Dir. Cement Clinic to 414'

40 5x8.21 Clin C @ 1516' Top 7 salt

40 5x8 Clin C @ 2750' Base 7 salt

8⁵/₈ 24 43" 4953'9¹/₂ cut @ 4593' - 75 5x8 Clin C

E Perf + 0.13 @ 7197' w/ 40 5x8 H

25 5x8 Clin H @ 9600'

TBC @ 9650'

CIBP @ 10672' - 25 5x8 Clin H on top.
E WC Perfs: 10772-10829'5¹/₂ 17" @ 11030'

OA TO 11,640'

{ }

**CONDITIONS OF APPROVAL
FOR PLUGGING AND ABANDONMENT
OCD - Southern District**

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office I (Hobbs) at **(575)-263-6633** at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down.

Company representative will be on location during plugging procedures.

1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
3. Trucking companies being used to haul oilfield waste fluids to a disposal - commercial or private- shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
8. Produced water will not be used during any part of the plugging operation.
9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
11. Class 'C' cement will be used above 7500 feet.
12. Class 'H' cement will be used below 7500 feet.
13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.
16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).

19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
- A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) Potash---(In the R-111-P Area (Potash Mine Area),
A solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing.

DRY HOLE MARKER REQUIREMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name
2. Lease and Well Number
3. API Number
4. Unit letter
5. Quarter Section (feet from the North, South, East or West)
6. Section, Township and Range
7. Plugging Date
8. County

SPECIAL CASES -----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

Well Sketch Present -
(Prior to P2A)

June 6, 2022

Phillips State # 1

API 30-025-01271


1980 FSL X 660 FEL

Unit Letter I, Section 25, T16S, R33E

Lea County, New Mexico

Spud 6/18/1957

After Conversion to SWD



www.pwllc.net

Phillips State #1

API # 30.025-01271

E. Sec 25 - T12S - R 33E

Proposed
Atty Plugging

6/6/2022

Lea Court, NM

mym

13³/₈ 48" 354'

Dir. Cement Clinic to 414'

40 5x5.21 Clin C @ 1516' Top of salt

40 5x5 Clin C @ 2750' Base of salt

8⁵/₈ 24 43" 4953'9¹/₂ cut @ 4593' - 75 5x5 Clin C

E Perf + 0.12 @ 7197' w/ 40 5x5 H

25 5x5 Clin H @ 9600'

TBC @ 9650'

CIBP @ 10672' - 25 5x5 Clin H on top.
E WC Perfs: 10772-10829'5¹/₂ 17" @ 11030'

OA TO 11,640'

{ }

District I
1625 N. French Dr., Hobbs, NM 88240
Phone:(575) 393-6161 Fax:(575) 393-0720
District II
811 S. First St., Artesia, NM 88210
Phone:(575) 748-1283 Fax:(575) 748-9720
District III
1000 Rio Brazos Rd., Aztec, NM 87410
Phone:(505) 334-6178 Fax:(505) 334-6170
District IV
1220 S. St Francis Dr., Santa Fe, NM 87505
Phone:(505) 476-3470 Fax:(505) 476-3462

State of New Mexico
Energy, Minerals and Natural Resources
Oil Conservation Division
1220 S. St Francis Dr.
Santa Fe, NM 87505

COMMENTS

Action 114950

COMMENTS

Operator: TLT SWD, LLC P.O. Box 1906 Hobbs, NM 88241	OGRID: 287481
	Action Number: 114950
	Action Type: [C-103] NOI Plug & Abandon (C-103F)

COMMENTS

Created By	Comment	Comment Date
plmartinez	DATA ENTRY PM	6/17/2022

District I
1625 N. French Dr., Hobbs, NM 88240
Phone:(575) 393-6161 Fax:(575) 393-0720
District II
811 S. First St., Artesia, NM 88210
Phone:(575) 748-1283 Fax:(575) 748-9720
District III
1000 Rio Brazos Rd., Aztec, NM 87410
Phone:(505) 334-6178 Fax:(505) 334-6170
District IV
1220 S. St Francis Dr., Santa Fe, NM 87505
Phone:(505) 476-3470 Fax:(505) 476-3462

State of New Mexico
Energy, Minerals and Natural Resources
Oil Conservation Division
1220 S. St Francis Dr.
Santa Fe, NM 87505

CONDITIONS

Action 114950

CONDITIONS

Operator: TLT SWD, LLC P.O. Box 1906 Hobbs, NM 88241	OGRID: 287481
	Action Number: 114950
	Action Type: [C-103] NOI Plug & Abandon (C-103F)

CONDITIONS

Created By	Condition	Condition Date
kfortner	See attached COA	6/17/2022