

Well Shugart "B" #3
Unit N Section 33 Township 18 Range 3
API # 30-015-05672

T. Salt 400
B. Salt 2165
Yates 2360
Glorieta _____
Delaware _____
Bone Sp. _____
Abo _____
Wolfcamp _____
Morrow _____
Devonian _____
Fusselman _____
Other _____

← Perf 8 7/8" 5 1/2" csg. @ 60' -
Place cmt. 0'-60' in & outside
of both csg. strings.

← Place 100' of cmt inside & outside csg
805' - 905' - Tag

← Perf csg @ 905'

← Place 100' of cmt 2165-2265' inside & outside csg. - Tag

← Perf csg. @ 2265'

TOC @ 50% calc.

← 25 5/8" plug @ 3300' Tag

Perfs Perfs sgd Dec 82

Perfs

← Permanent Bridge Plug @ 3500' Feb. 1971

Perfs

3625'

100 5/8"
7 7/8" hole

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up. Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.

BEFORE EXAMINER CATANACH
OIL CONSERVATION DIVISION

OCD EXHIBIT NO. 26

CASE NO. 12965