	1015
T. Sait	
B. Salt	
Yates	
Glorieta	
Delaware	
Bone Sp.	
Abo	
Wolfcamp	
Morrow	
Devonian	
Fusselman	
Other	

- Contact OCD 24 hrs. prior to any work done
- Salt gel mud consisting of 10# brine with 25;
  of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- . Plugs are to be set from point indicated up
- Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0'- 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.