

Division Approved Plugging Program

Gibson Oil Corp.
John Bergin #2 F-21-29N-11W

BEFORE EXAMINER STOGNER
OIL CORP. OF NEW MEXICO
<u>OCN</u>
CASE NO. <u>8862</u>

Downhole Equipment
Hole of unknown diameter, drilled
to 660'. Uncased.

1. Clean out hole to TD 660'
2. Set a cement plug 660' - 500'
3. Wait on cement a minimum of 4 hours.
4. Go in hole with tubing and tag plug. If plug is in place, go to step 5. If not, fill to 500'.
5. Set a cement plug 150' to surface.
6. Erect dry hole marker.
7. Fill pits, clean and level location.

All plugs will be with neat cement with or without CaCl_2

COUNTY <u>San Juan</u>		STATE <u>NEW MEXICO</u>
FIELD OR AREA	SEC. <u>21</u>	T. <u>29N</u> R. <u>11W</u>
LEASE <u>John Bergin</u>	LOCATION <u>2440' N 1520' W</u>	
COMPANY <u>Gibson Oil Corp.</u>	WELL NO. <u>2</u>	
ELEV. <u>Gibson</u>	SFD. <u>5-13-25</u>	COMPLETED <u>6-5-25</u>
CASING	T.D. <u>660'</u>	P.B.
SHOT OR ACID		
PERF.		
I.P.		
PRODUCING FORM.		
PRODUCTIVE DEPTH OR INTERVAL		

REMARKS:

P&A

4321 SE
FLORA VISTA
124 000

Gibson Oil Corp.
John Bergin #2 F-21-29N-11W
UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

