

Operator C.E. LARUE + B.N. Murry Jr.
Well 1Y-Villa
Unit D Section 8 Township 23 Range 28
API # 30-015--22302

Re-Plug

Drill out Plug
110' - 210'

TOC 260' Drill TO 320'
Set CIBP @ 318'

CMT TO SURFAC.

CMT TO
SURF.
CIBP - 318'
TOC 320'
8 5/8"
CSC
359'
CIRC.

MARCH 26, 2004

TOPS
T. Salt SALDO 430'
B. Salt 2200
Yates _____
Glorieta _____
Delaware 2470
Bone Sp. _____
Abo _____
Wolfcamp _____
Morrow _____
Devonian _____
Fusselman _____
Other _____

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up. Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.