

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

Oil Cons.  
N.M. DIV-Dist. 2  
1301 W. Grand Avenue  
Artesia, NM 88210

Budget Bureau No. 1004-0135  
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT - " for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5. LEASE DESIGNATION AND SERIAL NO. LC-029419-A	
2. NAME OF OPERATOR The Wiser Oil Company		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR P.O. Box 2568 Hobbs, New Mexico 88241		7. UNIT AGREEMENT NAME Skelly Unit	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 2630' FNL & 1330' FWL Unit F		8. WELL NAME AND NO. 115	
		9. API WELL NO. 30-015-21089	
		10. FIELD AND POOL, OR WILDCAT Grayburg Jackson 7-Rivers-QN-GB-SA	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 22-T17S-R31E	
14. PERMIT NO	15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3837' FR	12. COUNTY OR PARISH Eddy County	13. STATE NM

16. Check Appropriate Box to indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETE <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>

(Other) Plug and Abandon

SUBSEQUENT REPORT OF:

WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT * <input type="checkbox"/>
(Other) _____	

(Note: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS: (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Wiser requests approval to Plug and Abandon the well by the procedure listed below.

Surface Casing: 8-5/8" set @ 666'

Production Casing: 5-1/2" set @ 3981'

Perfs: 3350'-3832' 2234'-2350' CIBP @ 2180' ± 3202'

1. ~~Drill out~~ Spot 50' plug on CIBP @ 2180'.
2. Tag cement plug. SPOT 35' OF CEMENT ON TOP OF CIBP @ 3202'.
3. Circulate abandonment mud. 4. SET CIBP @ 2180' ± SPOT 35' OF CEMENT ON TOP or SET CEMENT PLUG FROM 2180-2400' TAG.
5. Spot 50' cement plug @ 1720' to 1670' 1820'.
6. Tag cement plug. SPOT 100' GHT PLUG @ 600-700' TAG.
7. Perforate casing @ 200' and circulate cement to surface. Leave a 50' plug @ 200' to 150'.
8. Tag cement.
9. Spot 50' cement plug to surface.
10. Install dry hole marker.
11. Clean location.

APPROVAL SUBJECT TO  
GENERAL REQUIREMENTS AND  
SPECIAL STIPULATIONS ATTACHED

18. I hereby certify that the foregoing is true and correct.

SIGNED Alexis C. Swoboda TITLE Prod. Supt. DATE April 1, 2003

(This space for Federal or State office use)

(ORIG. SGD.) ALEXIS C. SWOBODA

APPROVED BY \_\_\_\_\_ TITLE PETROLEUM ENGINEER DATE APR 08 2003

CONDITIONS OF APPROVAL, IF ANY:

\*See Instruction On Reverse Side