

RECEIVED
NOV 30 2004

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-100
Revised 1-1-00

DISTRICT I
P.O. Box 1900, Hobbs, NM 88240

OIL CONSERVATION DIVISION

2040 Pacheco St.
Santa Fe, NM 87505

DISTRICT II
P.O. Drawer 20, Arroyo NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO. 80-008-10463
Indicate Type of Lease STATE ☒ FEE ☐
State Oil & Gas Lease No. VA-613
Lease Name or Unit Agreement Name Avalanche Journal State
Well No. 1
Pool name or Wildcat ACME (San Andres)

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)							
Type of Well: OIL WELL ☒ GAS WELL ☐ OTHER ☐							
Name of Operator Roger P. Slayton DBA Escudilla Oil Company							
Address of Operator P. O. Box 687 Roswell, New Mexico 88203							
Well Location Unit Letter F : 1980 Feet From The North Line and 1930 Feet From The West Line Section 4 Township 8S Range 27E N4PM CHAVEZ County Elevation (Show whether OF, RKB, RT, OR, etc.) 3852 Gr							

11

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐
 TEMPORARILY ABANDON ☐ CHANGE PLANE ☐
 PULL OR ALTER CASING ☐
 OTHER: Convert to water disposal ☒

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
 COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
 CASING TEST AND CEMENT JOB ☐
 OTHER: ☐

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Rig up well service unit, with reverse unit.
- 2) Run 2 3/8" tubing with 4 3 1/8" drillcollars and 5 1/2" rotary bit.
- 3) Rig up portable mud pit and 4" x 6" duplex mud pit and drill cement plug from 1866' to 1922' and wash frac sand to PB depth of 1967' and clean out to casing shoe at 1974'.
- 4) Pull tubing, drill collars and bit.
- 6) Rig up perforators and perforate 4 holes 1967' to 1970' and reperforate with 2 holes per foot 1937' to 1957'.
- 6) Run seating nipple, tension setting packer on 2 3/8" internally plastic coated tubing and set packer at approximately 1900'.
- 7) Run injectivity test and treat as necessary.
- 8) Place on injection.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

Accepted for record

TITLE Operator

DATE 10-18-2004

TYPE OR PRINT NAME Roger P. Slayton

TELEPHONE NO. 505-625-5552

State of New Mexico

APPROVED BY

TITLE

DATE

County of Bernalillo

This may not be approved without benefit of

on approved 11-10-04

NOV 20 2004