

Operator Nadel & Gussman

TOPS

Well Tornillo 18 S 1 E 1Unit #1 Section 78 Township 21 Range 24API # 30-015-34137

VERBAL
Approval to
Given
Josh 7-11-05

New
Drill - P: A
off DELG. R. is

Yates _____
T. Salt _____
B. Salt _____
Glorieta 2215
Bone Sp. 4357
Abo _____
Wolfcamp 6432
Morrow 9342
Devonian _____
Fusselman _____
Other _____

0-60' Tag

400-500

1150-1250-Tag
2100-2200
4200-4300

6300-6400

7200-7300

100' Plugs

9200-9300

9 5/8"
@
1200'
Circ

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up. Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.