

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-015-23615
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. L-7017
7. Lease Name or Unit Agreement Name Flower Draw Unit
8. Well No. 1
9. Pool name or Wildcat Red Bluff Delaware (Gas)

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:  
OIL WELL ☐ GAS WELL ☒ OTHER

2. Name of Operator  
Parker & Parsley Development Company ✓

3. Address of Operator  
P.O. Box 3178, Midland, Texas 79702-3178

4. Well Location  
Unit Letter G : 1980 Feet From The North Line and 1980 Feet From The East Line

Section 2 Township 26S Range 28E NMPM Eddy County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)  
2974 RKB

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Set 9-5/8 CIBP at 3033' and cap w/ 15 sacks of cement.
- 2) Load hole w/ mud.
- 3) Spot 50 sacks of cement at 2814'. W.O.C. Tagged at 2728'.
- 4) Spot 15 sacks of cement at 2728'.
- 5) Spot 65 sacks of cement at 565'.
- 6) Spot 15 sacks of cement at surface and set up P.A. marker.
- 7) Backfilled cellar & cleaned location, removed pit-liner plastic.

Post ID-2  
5-1-92  
RHT

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Bob Yeates TITLE Consulting Engineer DATE 4/15/92  
TYPE OR PRINT NAME Bob Yeates TELEPHONE NO. 915-683-4768

(This space for State Use)

APPROVED BY Mark S. Williams TITLE OIL AND GAS INSPECTOR DATE JUN 10 1992  
CONDITIONS OF APPROVAL, IF ANY: