Submit 1 Copy To Appropriate District Office	State of New M		Form C-103		
<u>District I</u> – (575) 393-6161 1625 N. French Dr., Hobbs, NM 88240	Energy, Minerals and Nat	ural Resources	Revised July 18, 2013 WELL API NO.		
District II - (575) 748-1283	OIL CONSERVATION	DIVISION	30-015-22567		
811 S. First St., Artesia, NM 88210 District III - (505) 334-6178	1220 South St. Fra		5. Indicate Type of Lease		
1000 Rio Brazos Rd., Aztec, NM 87410 District IV – (505) 476-3460	Santa Fe, NM 8		STATE     FEE       6. State Oil & Gas Lease No.		
1220 S. St. Francis Dr., Santa Fe, NM					
(DO NOT USE THIS FORM FOR PROP	FICES AND REPORTS ON WELL OSALS TO DRILL OR TO DEEPEN OR PL	UG BACK TO A	7. Lease Name or Unit Agreement Name Bigfoot State		
PROPOSALS.)	JCATION FOR PERMIT" (FORM C-101) F	OR SUCH	8. Well Number 1		
1. Type of Well: Oil Well	Gas Well Other				
2. Name of Operator COG Operating, LLC			9. OGRID Number 229137		
3. Address of Operator			10. Pool name or Wildcat		
600 W. Illinois Ave, Midland, T	X 79701		Winchester, Wolfcamp, NW (oil)		
4. Well Location					
Unit Letter K	<b>1980</b> feet from the <u>S</u>	line and			
Section 20	Township 19S	Range 28E	NMPM County EDDY		
	11. Elevation (Show whether DI 3476'	к, <i>ккв, к1</i> , <i>G</i> к, еіс			
		·····			
12. Check	Appropriate Box to Indicate N	Nature of Notice,	, Report or Other Data		
	** *		-		
	NTENTION TO: ] PLUG AND ABANDON 🖾	REMEDIAL WOR	SEQUENT REPORT OF:		
TEMPORARILY ABANDON					
PULL OR ALTER CASING		CASING/CEMEN			
CLOSED-LOOP SYSTEM	]	OTHER:			
13. Describe proposed or com	pleted operations. (Clearly state all	pertinent details, ar	nd give pertinent dates, including estimated date		
of starting any proposed v	work). SEE RULE 19.15.7.14 NMA	C. For Multiple Co	ompletions: Attach wellbore diagram of		
proposed completion or re	ecompletion.				
1. Tag 5 ½" CIBP @ 10880	' w/ 35 sx cmt on top.				
2 Set 5 1/3" CIBP @ 8815'	Circulate hole w/ MLF Pressure tes	t csg. Spot 25 sx cm	nt @ 8815-8700' WVE & TAG		
3. Perf & Sqz 50 sx cmt @ 4	5650-65507. 6700' to 6600'-	- WOCFTAG			
	4550-4450'.— <b>WOC J TAG</b> 2888-2788'. WOC & Tag ( 9 5/8'' SI	noe)	4		
6. Perf & Sqz 50 sx cmt @	1580-1480'. (Queen) - WOC -	TAG			
7. Perf & Sqz 50 sx cmt @ 3	700-600'. WOC & Tag (Yates) - 6	uoe d-tag	re only receipe		
<ol> <li>Perf &amp; Sqz 100 sx cmt @</li> <li>Cut off well head, verify</li> </ol>	cmt to surface, weld on Dry Hole M	arker.	( well bot pendil Plugder		
······································			Juse in service of the Page		
			Aptroved for plugging of well bore only Aptroved for plugging is received pending receipt Aptroved for plugging is received with Page under Aptroved for plugging is received at OCD Web Page under Aptroved for plugging is received at OCD web page under Aptroved for plugging is received at OCD web page under Aptroved for plugging is received at OCD web page under Aptroved for plugging is received at OCD web page under		
<u> </u>		<b></b>	Approx on the set of t		
Spud Date:	Rig Release I	Date:	Listerios mar for reinte		
		11/10	Approved for plugging of well bore on y recanged Approved for plugging of well bore on Well Page under Approved for plugging is recained of Well Page under Approved in row be word at OCD Web Page under Listeries under be word at OCD Web Page under Listeries under be word at OCD Web Page under Approved for plugging at the opposite of the oppos		
WELL MUST BE	PLUBBED BY Y.	11118			
I hereby certify that the information	on above is true and complete to the	best of my knowled	ge and belief.		
SIGNATURE Alizail	Montgometry TITLE A	aent	DATE 9/6/17		
	abbu	rebunandas	sociates.com		
Type or print name Albigail Montgomery E-mail address: PHONE: 432-580-7161					
APPROVED BY: Johnt J. Rule TITLE COMPLIANCE OFFICER DATE 9/11/17					
APPROVED BY:	TITLE CO	MPLIANEE	OFFICER DATE 7/1///		
Conditions of Approval (if any):	-				
,					

#SFE	ATTACHED	COA-S
------	----------	-------

Author:	MRM (8/2017)			
Well Name	Bigfoot State	Well No.	#1	
Field	Winchester		30-015-22567	1 1
County	Eddy	Prop #:	37073	
State	New Mexico	Zone:	Morrow	
Spud Date	4/19/2008		1980 FSL & 2180 FWL	
Re-Spud Date	9/26/2008		Sec 20 T19S R28E	ור
GL	3,476	_		
КВ		_		


Description	O.D.	Grade	Weight	Depth	Cmt Sx	тос
Surface Csg	13.375"	?	48	418'	700	surface
Inter Csg	9.625"	?	36	2,835'	1,300	surface
Prod Csg	5 5"	?	17	11,073'	950	6,700'
Liner						


Marbob driller COG took ov

0 351

10 199

10,736





32.6442375

# CONDITIONS FOR PLUGGING AND ABANDONMENT

## District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If the well is not plugged within 1
- 7. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 8. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 9. Produced water will not be used during any part of the plugging operation.
- 10. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 11. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 12. Class 'C' cement will be used above 7500 feet.
- 13. Class 'H' cement will be used below 7500 feet.
- 14. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 15. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, **(WOC 4 hrs and tag)**.
- 19. No more than **3000' is allowed between cement plugs in cased hole and 2000' in open hole.**
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
  - A) Fusselman
  - B) Devonian
  - C) Morrow
  - D) Wolfcamp
  - E) Bone Springs
  - F) Delaware
  - G) Any salt sections
  - H) Abo
  - I) Glorieta
  - J) Yates.
  - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

## DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3. API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County

### (SPECIAL CASES)

### AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact