Form 3160-5 (August 1999)

UNITED STATES DEPARTMENT OF THE INTERIOR **BUREAU OF LAND MANAGEMENT**

	1	FOR
OCD-AKI	AIR	OMB
	7~**	Expires:

M APPROVED NO. 1004-0135

November 30, 2000

5. Lease Serial No. NM-85893

SUNDRY	•	NC	OTIC	ES	AND	REF	POF	RTS	ON	WELLS	

Do not use this form for proposals to drill or to re-enter an

6. If Indian, Allottee or Tribe Name abandoned well. Use Form 3160-3 (APD) for such proposals. 7. If Unit or CA/Agreement, Name and/or No. SUBMIT IN TRIPLICATE - Other instructions on reverse side 1. Type of Well 8. Well Name and No. X Oil Well Gas Well Other Cedar Canyon 21 2Y 2. Name of Operator Federal OXY USA Inc. 16696 9. API Well No. 3a. Address 3b. Phone No. (include area code) 30-015-29491 432-685-5717 P.O. Box 50250 Midland, TX 10. Field and Pool, or Exploratory Area 4. Location of Well (Footage, Sec., T., R., M., or Survey Description) Cedar Canyon Delaware JUN 10 2008 2310 FNL 890 FEL SENE(H) Sec 21 T24S R29E OCD-ARTESIA 11. County or Parish, State Eddy CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA 12. TYPE OF ACTION TYPE OF SUBMISSION Notice of Intent Acidize Deepen Production (Start/Resume) Water Shut-Off Alter Casing Fracture Treat Well Integrity Reclamation Subsequent Report Casing Repair New Construction Other Drill Out Recomplete Change Plans Plug and Abandon Temporarily Abandon CIBP and open up Final Abandonment Notice Water Disposal Convert to Injection Plug Back existing perfs

- 13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the final site is ready for final inspection.)
 - 1. Check for overhead power lines. Check wellhead pressure. RUPU.
 - 2. POOH w/ lift equipment.
 - RIH w/ work string and knock out CIBP set at 5110' and push past 5330'
 - 4. Clean out to bottom. Attempt to circulate well. Report findings to engineer.

5. RIH w/ new lift design equipment and place well on production.

6. RDPU.

APPROVED 9 2008 JUN

> JAMES A. AMOS SUPERVISOR-EPS

14. I hereby certify that the foregoing is true and correct Name (Printed/Typed) David Stewart	Title Sr. Regulator	ile Sr. Regulatory Analyst			
Va. Stat	Date 6/3/08				
THIS SPACE FO	OR FEDERAL OR STATE OFFICE US	E			
Approved by	Title	Date			
Conditions of approval, if any, are attached. Approval of this notice do certify that the applicant holds legal or equitable title to those rights in which would entitle the applicant to conduct operations thereon.					