Submit 3 Copies To Appropriate District Office	State of New Mexico		Form C-103	
District I 1625 N. French Dr., Hobbs, NM 88240	Energy, Minerals and Natural Resources		June 19, 2008 WELL API NO.	
<u>District II</u> 1301 W. Grand Ave., Artesia, NM 88210	OIL CONSERVATION DIVISION		30-015-24067	
District III	1220 South St. Francis Dr.		5. Indicate Type of Lea STATE	se FEE
1000 Rio Brazos Rd., Aztec, NM 87410 <u>District IV</u>	Santa Fe, NM 87505		6. State Oil & Gas Leas	
1220 S. St. Francis Dr., Santa Fe, NM 87505			VA-6407	
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH			7. Lease Name or Unit	Agreement Name
			Baccarat BJG State	
PROPOSALS.)			8. Well Number	
Type of Well: Oil Well      Name of Operator	Gas Well Other	ALIC 10 2000	9. OGRID Number	-
Yates Petroleum Corporation	•	AUG 18 2008	025575	
3. Address of Operator	<del></del>	CO-ARTESIA	10. Pool name or Wildo	eat eat
105 South Fourth Street, Artesia, 1	NM 88210	-	Wildcat; Delaware	
4. Well Location	,,,,,,,,,,,,,,			
Unit Letter K: 1980 feet from the South line and 1980 feet from the West line				
Section 5	Township 24S	Range 27E	NMPM Eddy	County
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3209'GR				
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data				
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:				
PERFORM REMEDIAL WORK				RING CASING
TEMPORARILY ABANDON	CHANGE PLANS		LLING OPNS.□ PAN	DA 🗆
PULL OR ALTER CASING	MULTIPLE COMPL	] CASING/CEMEN	T JOB	
DOWNHOLE COMMINGLE				
OTHER:		OTHER:		
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion				
or recompletion.				
Notify OCD 24 hrs. prior				
Yates Petroleum Corporation plans to plug and abandon this well as follows:  To any work done.				
1. Rig up all safety equipment as needed. No casing recovery will be attempted.				
2. Set a CIBP at 4124' with 35' cement on top. Load the hole with plugging mud.				
3. Spot a 25 sx cement plug from 2060'-2160'. This will place a plug across the 10-3/4" intermediate casing shoe and over old perfs 2132'-2198'. WOC and tag reset if necessary.				
4. Spot a 25 sx cement plug from 359'-459'. This will place a plug across the 16" surface casing shoe. WOC and tag reset if necessary.				
5. Spot a 25 sx cement plug from 100' to surface. This will form the surface plug. WOC and tag reset if necessary.				
6. Remove all surface equipment and weld dry hole marker as per regulations.  Approval Granted providing work is complete by 12/1/08				
			is complete by	
Spud Date:	Rig Relea	ase Date:		
		L		
I hereby certify that the information above is true and complete to the best of my knowledge and belief.				
SIGNATURE CLINA	L. A. TITLE	Regulatory Compliance	Supervisor DATE	August 14, 2008
		regulatory Compilance	DATE _	1xugust 14, 2000
Type or print name Tina Hue	erta E-mail address:	tinah@ypcnm.com P	HONE: 575-748-	4168
For State Use Only	<i></i>			1
APPROVED BY:	when TITLE C	emplin ff	DATE_	19/08
Conditions of Approval (if any):				



