Sub pit 3 Copies To Appropriate District		Francisco Contraction	F 0.103				
Office	State of New M		Form C-103 May 27, 2004				
<u>District I</u> 1625 N. French Dr., Hobbs, NM 88240	Energy, Minerals and Nati		WELL API NO.				
District II	OIL CONSERVATION		30-015-28659				
1301 W. Grand Ave., Artesia, NM 88210 <u>District III</u>	strict III 1220 South St. Francis Dr.						
1000 Rio Brazos Rd , Aztec, NM 87410 District IV	Santa Fe, NM 8	7505	STATE X FEE 6. State Oil & Gas Lease No.				
1220 S. St. Francis Dr., Santa Fe, NM 87505	•		7. K-6854-2				
SUNDRY NOTION (DO NOT USE THIS FORM FOR PROPOS	CES AND REPORTS ON WELLS ALS TO DRILL OR TO DEEPEN OR PL		7. Lease Name or Unit Agreement Name Avalon (Delaware) Unit				
DIFFERENT RESERVOIR, USE "APPLIC	ATION FOR PERMIT" (FORM.C-101) F	OR SUCH	8. Well Number 238				
PROPOSALS.) 1. Type of Well: Oil Well 2. North Fayyon Mo	Gas Well X Other INJHOUG	CFIVED	7				
2. Name of Operator EXXON MO	RII CURPURALIUN I	OV 1 1 2009	9. OGRID Number 7673				
3. Address of Operator			10. Pool name or Wildcat				
P.O. BOX 4358, CORP-MI-0203,	HOUSTON, TX 77210 NMO	CD ARTESIA	Avalon; Delaware 3715				
4. Well Location	•						
	from the <u>SOUTH</u> line and <u>1485</u>		ST line				
Section 30 Township		EDDY County) 2649 CD				
	11. Elevation (Show whether DF 3295' GR	K, KKB, KI, GK, eic.) 3048 GR				
Pit or Below-grade Tank Application or							
			tance from nearest surface water				
Pit Liner Thickness: mil	Below-Grade Tank: Volume	,	onstruction Material				
12. Check A	ppropriate Box to Indicate N	Nature of Notice,	Report or Other Data				
NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING		REMEDIAL WOR	ILLING OPNS. P AND A				
OTHER: STEP RATE TES	ST PROCEDURE	OTHER: TE	MPORARY ABANDONMENT				
			d give pertinent dates, including estimated date ttach wellbore diagram of proposed completion				
Exxon Mobil requests approval to per	rform the attached "Step-Rate Tes	t" to determine lates	st formation injection properties.				
			ge and belief. I further certify that any pit or below- or an (attached) alternative OCD-approved plan				
	0.0						
SIGNATURE Mark Wel	Reio TITLE S	TAFF REGULATO	DRY SPECIALIST DATE 11/11/2009				
Type or print name MARK DEL PI	CO E-mail address: mark_del	pico@exxonmobil.c	<u>com</u> Telephone No. <u>281-654-1926</u>				
For State Use Only			,				
APPROVED BY: REMAND Conditions of Approval (if any):	NAE TITLE	Comple lance	OFFICER DATE 12/11/09				

ADU Step-Rate Tests



EXXONMOBIL US PRODUCTION WELL WORK PROCEDURE ADU 503, 238, 642, 516, 505, 507, 537, 523 Avalon Delaware Unit



CURRENT STATUS:

Well is currently injecting.

Well will be shut in at least 48 hours prior to beginning of step-rate test.

ExxonMobil will contact NM OCD no less than 48 hours prior to beginning of test.

OBJECTIVE:

Perform Step-Rate tests on water injectors to determine latest formation injection

properties.

Risk Assessment:

Injection well. Producing wells in the area have been known to have ± 5000 ppm H2S concentration in their flow stream. Caution should be taken to prevent un-expected H2S exposure.

RECOMMENDED PROCEDURE:

- 1. Ensure ExxonMobil has notified NM OCD of step rate test (48 hours in advance) and shut in the well for a minimum of 48 hours prior to testing. Execute energy Isolation procedures on all equipment, machinery and valves associated within work scope.
- 2. Check status of rig anchor test. Move in and rig up wireline unit and pump truck.
- 3. Kill well by bull heading field salt water down tubing until assured well is dead.
- 4. Nipple down tree. MIRU BOP and lubricator and test.
- 5. Make wireline run to TD with a tool of analogous O.D. as down-hole pressure gauge to ensure that we have the clearance to run the pressure gauge.
- 6. Set pressure gauge at appropriate depth (see Table 1 below). Consult attached wellbore diagrams for individual well down-hole configurations.
- 7. Start injection at lowest rate (Step 1 of Table 2) and continue to inject at higher rates according to the specifications in Table 2 (below). Each step will last one hour (8 hours total pump time).
- 8. Finish final step rate and stop pumping. Ensure well is dead. Keep kill (or pump) truck on location as needed. ND BOP and lubricator; NU WH.
- RDMO wireline unit and pump truck; RWTI. Return well to previous injection state. NM OCD needs to review the test data before an increase in injection rate or pressure can be approved and implemented.

ADU Step-Rate Tests

	U. Cher	ry Perfs	U. Brus						
Well	Тор	Bottom	Тор	Bottom	Gauge Depth				
-	ft	ft	ft	ft	ft				
238	2632	2754	3428	3604	2582				
503	2628	2704	3486	3666	2578				
505	2546	2662	3514	3564	2578				
507	2498	2610	3426	3600	2448				
516	2576	2690	3602	3670	2526				
523	2556	2682	3542	3738	2506				
537	2544	2688	3586	3642	2494				
642	2534	2668	3646	3678	2484				

Table 1: Step-Rate Test Information

		Step 1 Step 2		ер 2	Step 3		Step 4		Step 5		Step 6		Step 7		Step 8		1			
Well	Inj Water Rate	Inj Pressure	3	0%	60%		90%		120%		150%		180%		210%		240%		Total Bbis for Test	
.~ .	bpd	psi	Bbl/d	Bbls/hr	Bbl/d	Bbls/hr	Bbl/d	Bbls/hr	Bbl/d	Bbls/hr	Bbl/d	Bbls/hr	Bbl/d	Bbls/hr	Bbl/d	Bbls/hr	BbVd	Bbls/hr	,-	bbls
238	475	480	142 5	6	285	12	427 5	18	570	24	712 5	30	855	36	997 5	42	1140	48		214
503	430	430	129	5	258	11	387	16	516	22	645	27	774	32	903	38	1032	43		194
505	240	480	72	3	144	6	216	9	288	12	360	15	432	18	504	21	576	24		108
507	215	480	64 5	3	129	5	193 5	8	258	11	322 5	13	387	16	451 5	19	516	22		97
516	350	480	105	4	210	9	315	13	420	18	525	22	630	26	735	31	840	35		158
523	175	460	52 5	2	105	4	157 5	7	210	9	262 5	11	315	13	367 5	15	420	18		79
537	240	480	72	3	144	6	216	9	288	12	360	15	432	18	504	21	576	24		108
642	200	480	60	3	120	5	180	8	240	10	300	13	360	15	420	18	480	20	L	90

Table 2: Injection Test Specifications for All 8 Wells