

32. Acid, Shot, Fracture, Cement, Squeeze, Etc.:

1. 6141-6157' Acidize with 2000 gal of 7-1/2% NEFE Acid. Frac with 16,000 gal 75 Quality Foam, 11,000# 20-40 sand, and 12,000# 10-12 sand.
2. 6010-6024' Acidize with 2000 gal of 7-1/2% NEFE Acid. Frac with 20,000 gal 75 Quality Foam, 14,500# 20-40 sand, and 16,000# 12-20 sand.
3. 5725-5870' Acidize with 4000 gal of 7-1/2% NEFE Acid. Frac with 36,000 gal 75 Quality Foam, 25,000# 20-40 sand and 28,000# 12-20 sand.
4. 5296-5324' Acidize with 2000 gal of 7-1/2% NEFE Acid.
5. 5084-5114' Acidize with 2500 gal of 7-1/2% NEFE Acid. Frac with 18,000 gal of 75 Quality Foam and 11,600# 20-40 sand.
6. 4896-4968' Acidize with 4000 gal of 7-1/2% NEFE Acid. Frac with 40,000 gal 75 Quality Foam, 34,000# 20-40 sand, and 20,000# 10-20 sand.
7. 4284-4302' Acidize with 2000 gal of 7-1/2% NEFE Acid. Frac with 16,000 gal 75 Quality Foam, 14,500# 20-40 sand, and 5000# 10-20 sand.
8. 3652-3666' Acidize with 3000 gal of 7-1/2% NEFE Acid.