

8. ND BOPs. NU 13-5/8" - 3000# X 11" -5000# WKM type "SF" csg. head spool. Test spool to 1250 psi.
9. NU 10" - 5M BOP or 13-5/8" - 5M BOP (Note: 13-5/8" will require a DSA in order to NU)
Test Hydril to 2500 psi. Test Rams & Manifold to 5000 psi. Test csg. to 1500 psi before
Ø out.
10. Drill 8½" hole to 10810'.
11. Log as directed by Geologist.
12. If productive, Run 5½" csg.

Gas is dedicated.