Office	State of New Mexico	Form C-103
Office District I  Energy, 1	Minerals and Natural Resources	May 27, 2004
1625 N. French Dr., Hobbs, NM 88240		WELL API NO.
District II OII CC	ONSERVATION DIVISION	30-015-34265
1301 W. Gland Ave., Artesia, 1417 60210	20 South St. Francis Dr.	5. Indicate Type of Lease
1000 Pio Brazos Pd. Aztec NM 87410		STATE S FEE
District IV	Santa Fe, NM 87505	6. State Oil & Gas Lease No.
1220 S. St. Francis Dr., Santa Fe, NM 87505		L-3756
SUNDRY NOTICES AND REF	PORTS ON WELLS	7. Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL O		RED TANK ST COM
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERM	MIT" (FORM C-101) FOR SUCH	100 112 112 12 12 12 12 12 12 12 12 12 12 1
PROPOSALS.)	RECEIVED	8. Well Number 1
1. Type of Well: Oil Well Gas Well	Other DEC 5 2005	
2. Name of Operator		9. OGRID Number 015363
MURCHISON OIL &	GAS, INC. OCU-ARTES	10. Pool name or Wildcat
3. Address of Operator	DI VID. DI ANO TV. 75002 4609	DENIA COODDAY MODDOW
	BLVD., PLANO, TX. 75093-4698	PENASCO DRAW, MORROW
4. Well Location		
Unit Letter D : 660 feet fr	om the <u>NORTH</u> line and <u>60</u>	60 feet from the <u>WEST</u> line
Section 35 Towns	ship 18S Range 24E NM	PM County EDDY
	(Show whether DR, RKB, RT, GR, etc.	
Pit or Below-grade Tank Application  or Closure		
Pit type Depth to Groundwater Distan	nce from nearest fresh water well Dista	ance from nearest surface water
		struction Material
	<u> </u>	
12. Check Appropriate E	Box to Indicate Nature of Notice,	Report or Other Data
NOTICE OF INTENTIONS		050U5NT 05000T 05
NOTICE OF INTENTION 1	IO: SUB	SEQUENT REPORT OF:
PERFORM REMEDIAL WORK   PLUG AND A		
PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PL	ANS COMMENCE DRI	LLING OPNS. P AND A
PERFORM REMEDIAL WORK   PLUG AND A	ANS COMMENCE DRI	LLING OPNS.⊠ PAND A □
PERFORM REMEDIAL WORK  PLUG AND A TEMPORARILY ABANDON CHANGE PL PULL OR ALTER CASING MULTIPLE C	ANS COMMENCE DRI COMPL CASING/CEMEN	LLING OPNS. P AND A
PERFORM REMEDIAL WORK  PLUG AND A TEMPORARILY ABANDON CHANGE PL PULL OR ALTER CASING MULTIPLE COTHER:	ANS COMMENCE DRI COMPL CASING/CEMENT  OTHER:	LLING OPNS. P AND A T JOB M
PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PL PULL OR ALTER CASING MULTIPLE COTHER:  13. Describe proposed or completed operations	ANS COMMENCE DRI COMPL CASING/CEMEN  OTHER: s. (Clearly state all pertinent details, an	LLING OPNS. P AND A  T JOB  d give pertinent dates, including estimated date
PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PL PULL OR ALTER CASING MULTIPLE COTHER:  13. Describe proposed or completed operations of starting any proposed work). SEE RUL	ANS COMMENCE DRI COMPL CASING/CEMEN  OTHER: s. (Clearly state all pertinent details, an	LLING OPNS. P AND A T JOB M
PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PL PULL OR ALTER CASING MULTIPLE COTHER:  13. Describe proposed or completed operations	ANS COMMENCE DRI COMPL CASING/CEMEN  OTHER: s. (Clearly state all pertinent details, an	LLING OPNS. P AND A  T JOB  d give pertinent dates, including estimated date
PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PL PULL OR ALTER CASING MULTIPLE COTHER:  13. Describe proposed or completed operations of starting any proposed work). SEE RUL or recompletion.	ANS COMMENCE DRI COMPL CASING/CEMEN  OTHER: s. (Clearly state all pertinent details, an LE 1103. For Multiple Completions: A	LLING OPNS. P AND A  T JOB  d give pertinent dates, including estimated date ttach wellbore diagram of proposed completion
PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PL PULL OR ALTER CASING MULTIPLE COTHER:  13. Describe proposed or completed operations of starting any proposed work). SEE RUL or recompletion.  Spud 17-1/2" hole @ 02:00 HRS 11/27/05	ANS COMMENCE DRICE COMPL CASING/CEMENT CASIN	LLING OPNS. P AND A  T JOB  d give pertinent dates, including estimated date ttach wellbore diagram of proposed completion
PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PL PULL OR ALTER CASING MULTIPLE COTHER:  13. Describe proposed or completed operations of starting any proposed work). SEE RUL or recompletion.  Spud 17-1/2" hole @ 02:00 HRS 11/27/05 1 Float Shoe	ANS COMMENCE DRICASING/CEMENT CASING/CEMENT OTHER:  s. (Clearly state all pertinent details, and LE 1103. For Multiple Completions: Action Action 11 and 12 and 12 and 13 and 13 and 14 are completed as 14 and 15 and 15 and 15 and 15 and 16 are completed as 15 and 16 are completed as 16 and 17 and 18 are completed as 16 are co	LLING OPNS. P AND A  T JOB  d give pertinent dates, including estimated date ttach wellbore diagram of proposed completion
PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PL PULL OR ALTER CASING MULTIPLE COTHER:  13. Describe proposed or completed operations of starting any proposed work). SEE RUL or recompletion.  Spud 17-1/2" hole @ 02:00 HRS 11/27/05	ANS COMMENCE DRICASING/CEMENT CASING/CEMENT OTHER:  s. (Clearly state all pertinent details, and LE 1103. For Multiple Completions: Action Action 11 and 12 and 12 and 13 and 13 and 14 are completed as 14 and 15 and 15 and 15 and 15 and 16 are completed as 15 and 16 are completed as 16 and 17 and 18 are completed as 16 are co	LLING OPNS. P AND A  T JOB  d give pertinent dates, including estimated date ttach wellbore diagram of proposed completion
PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PL PULL OR ALTER CASING MULTIPLE COTHER:  13. Describe proposed or completed operations of starting any proposed work). SEE RUL or recompletion.  Spud 17-1/2" hole @ 02:00 HRS 11/27/05  1 Float Shoe 12 JTS 13-3/8" 68 #/FT	COMMENCE DRICASING/CEMENT CASING/CEMENT CASI	LLING OPNS. P AND A T JOB dive pertinent dates, including estimated date ttach wellbore diagram of proposed completion /8" casing as follows:
PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PL PULL OR ALTER CASING MULTIPLE COTHER:  13. Describe proposed or completed operations of starting any proposed work). SEE RUL or recompletion.  Spud 17-1/2" hole @ 02:00 HRS 11/27/05  1 Float Shoe 12 JTS 13-3/8" 68 #/F)  Set casing @ 381'. Cement as follows: 4	COMMENCE DRICASING/CEMENT CASING/CEMENT CASING/CEMENT OTHER:  s. (Clearly state all pertinent details, and LE 1103. For Multiple Completions: A 17 TK-55 BT&C 3847  00 SXS Class "C" + 2% CACL + 1/4 #/5	LLING OPNS P AND A T JOB divergence of proposed completion /8" casing as follows:  SX Celloflake. Centralizer @ 370' & 319'.
PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PL PULL OR ALTER CASING MULTIPLE CONTHER:  13. Describe proposed or completed operations of starting any proposed work). SEE RUL or recompletion.  Spud 17-1/2" hole @ 02:00 HRS 11/27/05  1 Float Shoe 12 JTS 13-3/8" 68 #/F)  Set casing @ 381'. Cement as follows: 4 Bump plug w/ 1430 PSI. Floats held. Cir	COMMENCE DRICASING/CEMENT CASING/CEMENT CASING/CEMENT OTHER:  s. (Clearly state all pertinent details, and LE 1103. For Multiple Completions: At 1103. For Multiple Completions: At 1104 TK-55 BT&C 3847  OO SXS Class "C" + 2% CACL + 1/4 #/5 reculated 56 SXS to reserve pit. WOC 4	LLING OPNS. P AND A  T JOB  d give pertinent dates, including estimated date ttach wellbore diagram of proposed completion  /8" casing as follows:  SX Celloflake. Centralizer @ 370' & 319'.  Hrs. Cut conductor and casing weld on "A"
PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PL PULL OR ALTER CASING MULTIPLE CONTHER:  13. Describe proposed or completed operations of starting any proposed work). SEE RUL or recompletion.  Spud 17-1/2" hole @ 02:00 HRS 11/27/05  1 Float Shoe 12 JTS 13-3/8" 68 #/FT  Set casing @ 381'. Cement as follows: 4 Bump plug w/ 1430 PSI. Floats held. Cir Section test to 550 PSI. NU BOP. Test B	COMMENCE DRICASING/CEMENT CASING/CEMENT CASING/CEMENT OTHER:  s. (Clearly state all pertinent details, and LE 1103. For Multiple Completions: At 1103. For M	LLING OPNS P AND A T JOB divergence of proposed completion /8" casing as follows:  SX Celloflake. Centralizer @ 370' & 319'.
PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PL PULL OR ALTER CASING MULTIPLE CONTHER:  13. Describe proposed or completed operations of starting any proposed work). SEE RUL or recompletion.  Spud 17-1/2" hole @ 02:00 HRS 11/27/05  1 Float Shoe 12 JTS 13-3/8" 68 #/F)  Set casing @ 381'. Cement as follows: 4 Bump plug w/ 1430 PSI. Floats held. Cir	COMMENCE DRICASING/CEMENT CASING/CEMENT CASING/CEMENT OTHER:  s. (Clearly state all pertinent details, and LE 1103. For Multiple Completions: At 1103. For M	LLING OPNS. P AND A  T JOB  d give pertinent dates, including estimated date ttach wellbore diagram of proposed completion  /8" casing as follows:  SX Celloflake. Centralizer @ 370' & 319'.  Hrs. Cut conductor and casing weld on "A"
PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PL PULL OR ALTER CASING MULTIPLE CONTHER:  13. Describe proposed or completed operations of starting any proposed work). SEE RUL or recompletion.  Spud 17-1/2" hole @ 02:00 HRS 11/27/05  1 Float Shoe 12 JTS 13-3/8" 68 #/FT  Set casing @ 381'. Cement as follows: 4 Bump plug w/ 1430 PSI. Floats held. Cir Section test to 550 PSI. NU BOP. Test B	COMMENCE DRICASING/CEMENT CASING/CEMENT CASING/CEMENT OTHER:  s. (Clearly state all pertinent details, and LE 1103. For Multiple Completions: At 1103. For Multiple Completions: At 1103. TK-55 BT&C 384.  OO SXS Class "C" + 2% CACL + 1/4 #/S reculated 56 SXS to reserve pit. WOC 4 OP to 600 PSI. OK. TIH. Test casing	LLING OPNS. P AND A  T JOB  d give pertinent dates, including estimated date ttach wellbore diagram of proposed completion  /8" casing as follows:  SX Celloflake. Centralizer @ 370' & 319'.  Hrs. Cut conductor and casing weld on "A"
PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PL PULL OR ALTER CASING MULTIPLE COTHER:  13. Describe proposed or completed operations of starting any proposed work). SEE RUL or recompletion.  Spud 17-1/2" hole @ 02:00 HRS 11/27/05  1 Float Shoe 12 JTS 13-3/8" 68 #/FT  Set casing @ 381'. Cement as follows: 4 Bump plug w/ 1430 PSI. Floats held. Cir Section test to 550 PSI. NU BOP. Test B HRS. Drill out shoe and resume drilling I	COMMENCE DRI CASING/CEMENT  OTHER:  S. (Clearly state all pertinent details, and LE 1103. For Multiple Completions: A:  The completion of 382'. Run 13-3  1' The completion of 384'.  Sand drill to a depth of 382'. Run 13-3  1' The completion of 384'.  ON SXS Class "C" + 2% CACL + 1/4 #/5  Treculated 56 SXS to reserve pit. WOC 4  OP to 600 PSI. OK. TIH. Test casing 12-1/4" OH.	LLING OPNS. PAND A  T JOB  d give pertinent dates, including estimated date ttach wellbore diagram of proposed completion /8" casing as follows:  SX Celloflake. Centralizer @ 370' & 319'. Hrs. Cut conductor and casing weld on "A" and shoe to 1000 PSI. OK. WOC total 18  ge and belief. I further certify that any pit or below-
PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PL PULL OR ALTER CASING MULTIPLE COTHER:  13. Describe proposed or completed operations of starting any proposed work). SEE RUL or recompletion.  Spud 17-1/2" hole @ 02:00 HRS 11/27/05  1 Float Shoe 12 JTS 13-3/8" 68 #/F1  Set casing @ 381'. Cement as follows: 4 Bump plug w/ 1430 PSI. Floats held. Cir Section test to 550 PSI. NU BOP. Test B HRS. Drill out shoe and resume drilling 1	COMMENCE DRI CASING/CEMENT  OTHER:  S. (Clearly state all pertinent details, and LE 1103. For Multiple Completions: A:  The completion of 382'. Run 13-3  1' The completion of 384'.  Sand drill to a depth of 382'. Run 13-3  1' The completion of 384'.  ON SXS Class "C" + 2% CACL + 1/4 #/5  Treculated 56 SXS to reserve pit. WOC 4  OP to 600 PSI. OK. TIH. Test casing 12-1/4" OH.	LLING OPNS. PAND A  T JOB  d give pertinent dates, including estimated date ttach wellbore diagram of proposed completion /8" casing as follows:  SX Celloflake. Centralizer @ 370' & 319'. Hrs. Cut conductor and casing weld on "A" and shoe to 1000 PSI. OK. WOC total 18  ge and belief. I further certify that any pit or below-
PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PL PULL OR ALTER CASING MULTIPLE COTHER:  13. Describe proposed or completed operations of starting any proposed work). SEE RUL or recompletion.  Spud 17-1/2" hole @ 02:00 HRS 11/27/05  1 Float Shoe 12 JTS 13-3/8" 68 #/FI  Set casing @ 381'. Cement as follows: 4 Bump plug w/ 1430 PSI. Floats held. Cir Section test to 550 PSI. NU BOP. Test B HRS. Drill out shoe and resume drilling I	COMMENCE DRICOMPL CASING/CEMENT CASING COMPLETE COMPLETE COMPLETE CASING CASING COMPLETE CASING CASING COMPLETE CASING CASI	LLING OPNS. PAND A Day Department dates, including estimated dates ttach wellbore diagram of proposed completion /8" casing as follows:  SX Celloflake. Centralizer @ 370' & 319'. Hrs. Cut conductor and casing weld on "A" and shoe to 1000 PSI. OK. WOC total 18  ge and belief. I further certify that any pit or belower an (attached) alternative OCD-approved plan
PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PL PULL OR ALTER CASING MULTIPLE COTHER:  13. Describe proposed or completed operations of starting any proposed work). SEE RUL or recompletion.  Spud 17-1/2" hole @ 02:00 HRS 11/27/05  1 Float Shoe 12 JTS 13-3/8" 68 #/FT  Set casing @ 381'. Cement as follows: 4 Bump plug w/ 1430 PSI. Floats held. Cir Section test to 550 PSI. NU BOP. Test B HRS. Drill out shoe and resume drilling I	COMMENCE DRI CASING/CEMENT  OTHER:  S. (Clearly state all pertinent details, and LE 1103. For Multiple Completions: A:  The completion of 382'. Run 13-3  1' The completion of 384'.  Sand drill to a depth of 382'. Run 13-3  1' The completion of 384'.  ON SXS Class "C" + 2% CACL + 1/4 #/5  Treculated 56 SXS to reserve pit. WOC 4  OP to 600 PSI. OK. TIH. Test casing 12-1/4" OH.	LLING OPNS. PAND A Day Description of proposed completion of give pertinent dates, including estimated date ttach wellbore diagram of proposed completion of proposed completion of proposed completion of track wellbore diagram of proposed completion of the proposed
PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PL PULL OR ALTER CASING MULTIPLE COTHER:  13. Describe proposed or completed operations of starting any proposed work). SEE RUL or recompletion.  Spud 17-1/2" hole @ 02:00 HRS 11/27/05  1 Float Shoe 12 JTS 13-3/8" 68 #/FT  Set casing @ 381'. Cement as follows: 4 Bump plug w/ 1430 PSI. Floats held. Cir Section test to 550 PSI. NU BOP. Test B HRS. Drill out shoe and resume drilling I	ANS COMMENCE DRICOMPL CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING COMPLETE COMPLETE COMPLETE COMPLETE CASING CASING COMPLETE CASING CASING COMPLETE CASING CA	LLING OPNS. PAND A  T JOB  d give pertinent dates, including estimated dates ttach wellbore diagram of proposed completion /8" casing as follows:  SX Celloflake. Centralizer @ 370' & 319'.  Hrs. Cut conductor and casing weld on "A" and shoe to 1000 PSI. OK. WOC total 18  ge and belief. I further certify that any pit or belower an (attached) alternative OCD-approved plan  DATE 12/1/2005
PERFORM REMEDIAL WORK  PLUG AND A TEMPORARILY ABANDON  CHANGE PL PULL OR ALTER CASING  MULTIPLE COTHER:  13. Describe proposed or completed operations of starting any proposed work). SEE RUL or recompletion.  Spud 17-1/2" hole @ 02:00 HRS 11/27/05 1 Float Shoe 12 JTS 13-3/8" 68 #/FI  Set casing @ 381'. Cement as follows: 4 Bump plug w/ 1430 PSI. Floats held. Cir Section test to 550 PSI. NU BOP. Test B HRS. Drill out shoe and resume drilling I	ANS COMMENCE DRICASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING COMPLETE COMPLETE COMPLETE COMPLETE CASING CASING COMPLETE CASING	LLING OPNS. PAND A  T JOB  d give pertinent dates, including estimated date ttach wellbore diagram of proposed completion  /8" casing as follows:  SX Celloflake. Centralizer @ 370' & 319'.  Hrs. Cut conductor and casing weld on "A" and shoe to 1000 PSI. OK. WOC total 18  ge and belief. I further certify that any pit or belower an (attached) alternative OCD-approved plan  rations  DATE 12/1/2005  y@jdmii.com  Telephone No. 972-931-0700
PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PL PULL OR ALTER CASING MULTIPLE COTHER:  13. Describe proposed or completed operations of starting any proposed work). SEE RUL or recompletion.  Spud 17-1/2" hole @ 02:00 HRS 11/27/05  1 Float Shoe 12 JTS 13-3/8" 68 #/FT  Set casing @ 381'. Cement as follows: 4 Bump plug w/ 1430 PSI. Floats held. Cir Section test to 550 PSI. NU BOP. Test B HRS. Drill out shoe and resume drilling I	ANS COMMENCE DRICASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING COMPLETE COMPLETE COMPLETE COMPLETE CASING CASING COMPLETE CASING	LLING OPNS. PAND A  T JOB  d give pertinent dates, including estimated date ttach wellbore diagram of proposed completion  /8" casing as follows:  SX Celloflake. Centralizer @ 370' & 319'.  Hrs. Cut conductor and casing weld on "A" and shoe to 1000 PSI. OK. WOC total 18  ge and belief. I further certify that any pit or belower an (attached) alternative OCD-approved plan  rations  DATE 12/1/2005  y@jdmii.com  Telephone No. 972-931-0700
PERFORM REMEDIAL WORK PLUG AND A TEMPORARILY ABANDON CHANGE PL PULL OR ALTER CASING MULTIPLE OF COTHER:  13. Describe proposed or completed operations of starting any proposed work). SEE RUL or recompletion.  Spud 17-1/2" hole @ 02:00 HRS 11/27/05 1 Float Shoe 12 JTS 13-3/8" 68 #/FI  Set casing @ 381'. Cement as follows: 4 Bump plug w/ 1430 PSI. Floats held. Cir Section test to 550 PSI. NU BOP. Test B HRS. Drill out shoe and resume drilling II  I hereby certify that the information above is true a grade tank has been/will be constructed or closed according SIGNATURE  Type or print name MICHAEL S. DAUGHERTY For State Use Only	COMMENCE DRICOMPL CASING/CEMENT CASING COMPLETE CASING CASING COMPLETE CASING CASING CASING COMPLETE CASING CASIN	LLING OPNS. PAND A  T JOB  d give pertinent dates, including estimated date ttach wellbore diagram of proposed completion  /8" casing as follows:  EX Celloflake. Centralizer @ 370' & 319'.  Hrs. Cut conductor and casing weld on "A" and shoe to 1000 PSI. OK. WOC total 18  ge and belief. I further certify that any pit or belower an (attached) alternative OCD-approved plan   parations  DATE 12/1/2005  y@jdmii.com  Telephone No. 972-931-0700  DEC 0 4 2003
PERFORM REMEDIAL WORK  PLUG AND A TEMPORARILY ABANDON  CHANGE PL PULL OR ALTER CASING  MULTIPLE COTHER:  13. Describe proposed or completed operations of starting any proposed work). SEE RUL or recompletion.  Spud 17-1/2" hole @ 02:00 HRS 11/27/05 1 Float Shoe 12 JTS 13-3/8" 68 #/FI  Set casing @ 381'. Cement as follows: 4 Bump plug w/ 1430 PSI. Floats held. Cir Section test to 550 PSI. NU BOP. Test B HRS. Drill out shoe and resume drilling I	ANS COMMENCE DRICASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING/CEMENT CASING COMPLETE COMPLETE COMPLETE COMPLETE CASING CASING COMPLETE CASING	LLING OPNS. PAND A  T JOB  d give pertinent dates, including estimated date ttach wellbore diagram of proposed completion  /8" casing as follows:  SX Celloflake. Centralizer @ 370' & 319'.  Hrs. Cut conductor and casing weld on "A" and shoe to 1000 PSI. OK. WOC total 18  ge and belief. I further certify that any pit or belower an (attached) alternative OCD-approved plan  rations  DATE 12/1/2005  y@jdmii.com  Telephone No. 972-931-0700