

OCD-ARTESIA

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1 Type of Well

☐ Oil Well ☐ Gas Well ☒ Other SWD-1019

2. Name of Operator

Chevron USA Inc.

3. Address and Telephone No.

P.O. Box 960, Artesia, NM 88211-0960

4. Location of Well (Footage, Sec., T. R., M. or Survey Description)

1100 FNL & 660 FEL, Sec. 14 T17S R31E

RECEIVED

MAR 28 2006

OCD-ARTESIA

(505)748-1288

5. Lease Designation and Serial No

NM-98120

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Skelly Unit #905

9. API Well No.

30-015-31371

10. Field and Pool, or Exploratory Area

SWD; Cisco

11. County or Parish, State

Eddy, NM

12 CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☐ Notice of Intent
☒ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☒ Other Convert to SWD

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13 Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work)*

02/09/2006 MIRU start drilling cement plugs.

02/10/2006 Tag plug @ 4049', test casing to 1000# held OK.

02/13/2006 Tag plug @ 5588', circulate hole clean. Set SV retainer @ 5062'.

02/14/2006 Squeezed perfs @ 5288-5360' w/200sx Class C and 200sx Class C neat.

02/15/2006 Start drilling SV and cement.

02/16/2006 Drill to 5362', test casing to 1000# for 5 minutes, held OK. Tag plug @ 6576', circulate hole clean. Set SV retainer @ 5624'.

02/17/2006 Squeezed perfs @ 5679-6276' w/200sx Class C and 200sx Class C neat.

02/21/2006 Finish drilling cement to 6276', tested casing to 500# for 20 minutes, held OK.

02/22/2006 Finish drilling to CIBP tag @ 10,600', circulate hole clean. Set CIBP @ 10,090'. Perforated from 9850-9902' 208 holes.

02/23/2006 Acidized w/5000 gals 15% HCL.

02/24/2006 RIH w/5 1/2" Arrowset Packer and 307 joints 2 7/8" L-80 plastic coated tubing, swab and find fluid level at 5000'. Set Packer @ 9794'. Load backside w/Packer fluid and test to 500# for 30 minutes, held OK. See attached chart.

Authority to inject may not be granted on this form.
Original chart must be submitted on NMOC Form

C-103.

ACCEPTED FOR RECORD

MAR 24 2006

14. I hereby certify that the foregoing is true and correct

Signed

James W. Shenell

Title

Production Clerk

ALEXIS C. SWOBODA
PETROLEUM ENGINEER

3/20/2006

(This space for Federal or State office use)

Approved by

Accepted for record

Title

Date

Conditions of approval, if any:

NMOC

