

Submit 1 Copy To Appropriate District Office.

District I - (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II - (575) 748-1283
811 S. First St., Artesia, NM 88210
District III - (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87410
District IV - (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

Form C-103
Revised July 18, 2013

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		WELL API NO. 30-015-28738
1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/>		5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
2. Name of Operator EOG Y Resources, Inc.		6. State Oil & Gas Lease No. E-10167
3. Address of Operator 104 South Fourth Street, Artesia, NM 88210		7. Lease Name or Unit Agreement Name Boyd X State
4. Well Location Unit Letter <u>H</u> : <u>1880</u> feet from the <u>North</u> line and <u>660</u> feet from the <u>East</u> line Section <u>16</u> Township <u>19S</u> Range <u>25E</u> NMPM Eddy County		8. Well Number 12
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3469' GR		9. OGRID Number 025575
		10. Pool name or Wildcat N. Seven Rivers; Glorieta-Yeso

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	P AND A <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	MULTIPLE COMPL. <input type="checkbox"/>	CASING/CEMENT JOB <input type="checkbox"/>	
DOWNHOLE COMMINGLE <input type="checkbox"/>			
CLOSED-LOOP SYSTEM <input type="checkbox"/>			
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

EOG Y Resources, Inc. plans to plug and abandon this well as follows:

Notify OCD 24 hrs. prior to any work done.

1. MIRU safety equipment as needed. POOH with TEC and gauge.
2. RIH with GR/JB to 2383'.
3. Set a CIBP at 2258' with 35' Class "C" cement on top. Fill hole with plugging mud. - woc + Tag
4. Perforate at 1251'. Attempt to establish circulation. Spot a 25 sx Class "C" cement plug from 1109'-1251'. This will plug the 9-5/8" casing shoe.
5. Spot a 25 sx Class "C" cement plug from 677'-819'. This will plug San Andres.
6. Spot a 10 sx Class "C" cement plug from 57' up to surface.
7. Cut off wellhead and install dry hole marker. Clean location as per regulated.

Wellbore schematic attached TA expires 1-18-2019

RECEIVED
ENTERED 1-18-2019
JAN 11 2019

Spud Date: RIG Release Date: DISTRICT II-ARTESIA O.C.D.

* See Attached COA: must be plugged by 1/11/20
I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Tina Huerta TITLE Regulatory Specialist DATE January 8, 2019

Type or print name Tina Huerta E-mail address: tina_huerta@eogresources.com PHONE: 575-748-4168
For State Use Only

APPROVED BY: [Signature] TITLE Staff mg. DATE 1/11/19
Conditions of Approval (if any): approval
emailed Tina copy - system is having difficulty accepting dates due to change of operator

Boyd X State #12		
COMMENTS		
	<p>The diagram shows a vertical wellbore with several sections. At the top, there is a section labeled 'A' which is a large rectangular area. Below this, the wellbore is divided into sections by horizontal lines. Perforations are indicated by wavy lines on the left and right sides of the wellbore. A black rectangular plug is shown in the center of the wellbore. Below the plug, there are several horizontal lines representing cement plugs. At the bottom, there is a section labeled 'B' which is a large rectangular area. The wellbore is shown with a central line and a surrounding casing line.</p>	
Perforations	2308 - 2434 2550 - 2625	
Cmt plug	4980 - 5190	
Cmt plug	5678 - 6055	
CIBP @ 7676 with 35 ft cmt Canyon Perfs	7726 - 7816	
	<p style="text-align: center;">B</p>	
	PBTD 5,860	MD
	TD 1,800	MD

[illegible][illegible][illegible]

#	SIZE	WGHT	GRADE	THREAD	Top	Bottom	CMT	
A	9 5/8	36	K-55		0	1,201	1200 sx	Circ
B	7	26	K-55		0	8,109	1400 sx	Circ

San Anders	769	
Glorieta	2307	
Bone Spring	3622	
Wolfcamp	5783	
Canyon	7629	

Prepared by: MJM

Boyd X State #12

COMMENTS	
<p>Perforate at 1251 ft. Attempt to establish Circulation. Spot a 25 SX (142 ft) CLS C cement plug 1109 ft - 1251 ft. This will plug the 9.625 inch casing shoe.</p>	
<p>Set CIBP at 2258 ft with 35 ft of CLS C on top.</p>	
<p>Perforations 2308 - 2434 2550 - 2625</p>	
<p>Cmt plug 4980 - 5190</p>	
<p>Cmt plug 5678 - 6055</p>	
<p>CIBP @ 7676 with 35 ft cmt Canyon Perfs 7726 - 7816</p>	
	<p>B</p>
	<p>PBTD 4,980 MD TD 8,255 MD</p>

[illegible]

Set CIBP at 2258 ft with 35 ft of CLS C on top.

Cmt plug	4980 - 5190
----------	-------------

Cmt plug	5678 - 6055
----------	-------------

CIBP @ 7676 with 35 ft cmt
Canyon Perfs 7726 - 7816

Spot a 25 SX (142 ft) CLS
C cement plug 677 ft -
819 ft. This will plug the
San Anders.

PSTD	4,980	MD
TD	8,255	MD

CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, **Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.**

1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs.
2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
3. Trucking companies being used to haul oilfield waste fluids to a disposal – commercial or private – shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
6. If the well is not plugged within 1
7. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
8. **Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.**
9. Produced water **will not** be used during any part of the plugging operation.
10. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
11. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
12. **Class 'C' cement will be used above 7500 feet.**
13. **Class 'H' cement will be used below 7500 feet.**
14. **A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged**
15. **All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing**

16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
17. **A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.**
18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, **(WOC 4 hrs and tag).**
19. **No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.**
20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) **Potash---** (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, **WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.**
21. **If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing**

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)-----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)