Submit 3 Copies To Appropriate District Office	State of New Mexico	Form C-103	
District I	Energy, Minerals and Natural Resources	June 19, 2008 WELL API NO.	
1625 N French Dr , Hobbs, NM 88240 District II	OH CONGEDUATION DIVIGION	30-015-37567	
1301 W. Grand Ave, Artesia, NM 88210 District III	OIL CONSERVATION DIVISION 1220 South St. Francis Dr.	5. Indicate Type of Lease	
1000 Rio Brazos Rd., Aztec, NM 87410	Santa Fe, NM 87505	STATE FEE	
<u>District IV</u> 1220 S. St. Francis Dr., Santa Fe, NM	Santa 1 C, 14141 67303	6. State Oil & Gas Lease No.	
87505 SLINDRY NOTIC	CES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name	
(DO NOT USE THIS FORM FOR PROPOS	ALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A		
DIFFERENT RESERVOIR. USE "APPLIC PROPOSALS)	ATION FOR PERMIT" (FORM C-101) FOR SUCH	GJ West Coop Unit RECEIVED	)
	Gas Well 🗌 Other	8. Well Number 231 AUG 1 9 2010	
2. Name of Operator		9. OGRID Number	
COG Operating LLC		229137 NMOCD ARTESI	<u>A</u>
3. Address of Operator 550 W. Texas Ave., Suite 1300 Mi	dland, TX 79701	10. Pool name or Wildcat GJ;7RVS-QN-GB-Glorieta-Yeso 97558	
4. Well Location	unding, 171 / / / / /	GS, ACTS QLT GD GIONEAL TESE 77330	
	1650 feet from the South line and 1650	feet from the East line	
Section 16		1PM County Eddy	
	11. Elevation (Show whether DR, RKB, RT, GR, e		
	3562 GR		
12 (1 1 4		D ( OI D)	
12. Check A	ppropriate Box to Indicate Nature of Notic	e, Report or Other Data	
NOTICE OF IN		JBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK	PLUG AND ABANDON REMEDIAL WO		
TEMPORARILY ABANDON   PULL OR ALTER CASING	CHANGE PLANS COMMENCE I MULTIPLE COMPL CASING/CEME	DRILLING OPNS.□ P AND A □ ENT JOB □ _	
DOWNHOLE COMMINGLE	MOETIFEE COMPE	LN JOB LJ ,	
		_	
OTHER:		Completion 🔟	
13. Describe proposed or compl	eted operations. (Clearly state all pertinent details,	and give pertinent dates, including estimated date	
13. Describe proposed or compl		and give pertinent dates, including estimated date	
13. Describe proposed or comploof starting any proposed wo or recompletion. 7/9/10 Test casing to 3500 p	eted operations. (Clearly state all pertinent details, rk). SEE RULE 1103. For Multiple Completions: osi for 30 mins. Ok.	and give pertinent dates, including estimated date	
of starting any proposed wo or recompletion. 7/9/10 Test casing to 3500 pt 7/12/10 Perf Lower Blinebry	eted operations. (Clearly state all pertinent details, rk). SEE RULE 1103. For Multiple Completions: osi for 30 mins. Ok.  © 5080-5280 w/ 1 SPF, 26 holes.	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion	
13. Describe proposed or complor of starting any proposed wood or recompletion. 7/9/10 Test casing to 3500 proposed work and the starting any proposed work and the starting any proposed work and the starting an	eted operations. (Clearly state all pertinent details, rk). SEE RULE 1103. For Multiple Completions: osi for 30 mins. Ok.  @ 5080-5280 w/ 1 SPF, 26 holes. s acid. Frac w/116,000 gals gel, 145,30	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 01# 16/30 White Sand, 35,296# 16/30	
of starting any proposed wo or recompletion.  7/9/10 Test casing to 3500 proposed work of the starting any proposed work of the starting any proposed work of the starting any proposed work of the starting and proposed with the starting and	eted operations. (Clearly state all pertinent details, rk). SEE RULE 1103. For Multiple Completions: osi for 30 mins. Ok.  © 5080-5280 w/ 1 SPF, 26 holes. s acid. Frac w/116,000 gals gel, 145,30 to 5040. Perf Middle Blinebry @ 4810-50	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 01# 16/30 White Sand, 35,296# 16/30 010 w/1 SPF, 26 holes. Acidize	
of starting any proposed woor recompletion.  7/9/10 Test casing to 3500 p  7/12/10 Perf Lower Blinebry  7/13/10 Acidize w/2,500 gals  Super LC. Set comp plug @  w/2500 gals acid. Frac w/ 1	eted operations. (Clearly state all pertinent details, rk). SEE RULE 1103. For Multiple Completions: osi for 30 mins. Ok.  @ 5080-5280 w/ 1 SPF, 26 holes. s acid. Frac w/116,000 gals gel, 145,30 to 5040. Perf Middle Blinebry @ 4810-5016,000 gals gel, 146,156# 16/30 White	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 0.1# 16/30 White Sand, 35,296# 16/30 0.10 w/1 SPF, 26 holes. Acidize Sand, 35,250# 16/30 Super LC. Set	
of starting any proposed or comploof starting any proposed wo or recompletion.  7/9/10 Test casing to 3500 proposed work of the starting any proposed work of the starting any proposed work of starting any proposed or complete work of starting any proposed work of starting and starti	eted operations. (Clearly state all pertinent details, rk). SEE RULE 1103. For Multiple Completions: osi for 30 mins. Ok. @ 5080-5280 w/ 1 SPF, 26 holes. s acid. Frac w/116,000 gals gel, 145,30 to 5040. Perf Middle Blinebry @ 4810-5016,000 gals gel, 146,156# 16/30 White per Blinebry @ 4540-4740 w/ 1 SPF, 2	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 01# 16/30 White Sand, 35,296# 16/30 010 w/1 SPF, 26 holes. Acidize Sand, 35,250# 16/30 Super LC. Set 66 holes. Acidize w/2,500 gals acid.	
of starting any proposed or complor of starting any proposed wo or recompletion.  7/9/10 Test casing to 3500 proposed work of the starting any proposed work of the starting any proposed work of the starting and proposed or complete work of the starting any proposed or complete work of starting any proposed or complete work of starting any proposed work of starting and starting an	eted operations. (Clearly state all pertinent details, rk). SEE RULE 1103. For Multiple Completions: osi for 30 mins. Ok. @ 5080-5280 w/ 1 SPF, 26 holes. s acid. Frac w/116,000 gals gel, 145,30 of 5040. Perf Middle Blinebry @ 4810-5016,000 gals gel, 146,156# 16/30 White per Blinebry @ 4540-4740 w/ 1 SPF, 2014,337# 16/30 White Sand, 31,548# 16	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 0.1# 16/30 White Sand, 35,296# 16/30 0.10 w/1 SPF, 26 holes. Acidize Sand, 35,250# 16/30 Super LC. Set 16 holes. Acidize w/2,500 gals acid. //30 Super LC. Set comp plug @	
of starting any proposed or comploar starting any proposed wo or recompletion.  7/9/10 Test casing to 3500 proposed work of the starting any proposed work of the starting and starting any proposed work of the starting and starting any proposed work of the starting any proposed or complete work of starting any proposed or complete work of starting any proposed work of starting any proposed or complete work of starting any proposed work of starting and s	eted operations. (Clearly state all pertinent details, rk). SEE RULE 1103. For Multiple Completions: osi for 30 mins. Ok. @ 5080-5280 w/ 1 SPF, 26 holes. s acid. Frac w/116,000 gals gel, 145,30 to 5040. Perf Middle Blinebry @ 4810-5016,000 gals gel, 146,156# 16/30 White per Blinebry @ 4540-4740 w/ 1 SPF, 2014,337# 16/30 White Sand, 31,548# 1603-4242. Acidize w/ 3,000 gals acid. Frace	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 0.1# 16/30 White Sand, 35,296# 16/30 0.10 w/1 SPF, 26 holes. Acidize Sand, 35,250# 16/30 Super LC. Set 16 holes. Acidize w/2,500 gals acid. //30 Super LC. Set comp plug @	
of starting any proposed or comploate of starting any proposed wood or recompletion.  7/9/10 Test casing to 3500 proposed wood or recompletion.  7/12/10 Perf Lower Blinebry 7/13/10 Acidize w/2,500 gals. Super LC. Set comp plug @w/2500 gals acid. Frac w/ 17 comp plug @ 4780. Perf Up Frac w/ 116,000 gals gel, 144272. Perf Paddock @ 3976 White Sand, 17,437# 16/30	eted operations. (Clearly state all pertinent details, rk). SEE RULE 1103. For Multiple Completions: osi for 30 mins. Ok. @ 5080-5280 w/ 1 SPF, 26 holes. s acid. Frac w/116,000 gals gel, 145,30 to 5040. Perf Middle Blinebry @ 4810-5016,000 gals gel, 146,156# 16/30 White per Blinebry @ 4540-4740 w/ 1 SPF, 214,337# 16/30 White Sand, 31,548# 166-4242. Acidize w/ 3,000 gals acid. Frac Super LC.	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 0.1# 16/30 White Sand, 35,296# 16/30 0.10 w/1 SPF, 26 holes. Acidize Sand, 35,250# 16/30 Super LC. Set 66 holes. Acidize w/2,500 gals acid. /30 Super LC. Set comp plug @ c w/ 101,000 gals gel, 111,793# 16/30	
of starting any proposed or comploate of starting any proposed wood or recompletion.  7/9/10 Test casing to 3500 proposed wood or recompletion.  7/12/10 Perf Lower Blinebry 7/13/10 Acidize w/2,500 gals. Super LC. Set comp plug @w/2500 gals acid. Frac w/ 17 comp plug @ 4780. Perf Up Frac w/ 116,000 gals gel, 144272. Perf Paddock @ 3976 White Sand, 17,437# 16/30	eted operations. (Clearly state all pertinent details, rk). SEE RULE 1103. For Multiple Completions: osi for 30 mins. Ok. @ 5080-5280 w/ 1 SPF, 26 holes. s acid. Frac w/116,000 gals gel, 145,30 of 5040. Perf Middle Blinebry @ 4810-5016,000 gals gel, 146,156# 16/30 White per Blinebry @ 4540-4740 w/ 1 SPF, 2014,337# 16/30 White Sand, 31,548# 160-4242. Acidize w/ 3,000 gals acid. Frac Super LC. n out to PBTD 5510. RIH w/160jts 2-7/8	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 0.1# 16/30 White Sand, 35,296# 16/30 0.10 w/1 SPF, 26 holes. Acidize Sand, 35,250# 16/30 Super LC. Set 66 holes. Acidize w/2,500 gals acid. /30 Super LC. Set comp plug @ c w/ 101,000 gals gel, 111,793# 16/30	
of starting any proposed wood or recompletion.  7/9/10 Test casing to 3500 proposed wood or recompletion.  7/12/10 Perf Lower Blinebry proposed wood or recompletion.  7/13/10 Acidize w/2,500 gals. Super LC. Set comp plug @w/2500 gals acid. Frac w/ 10 comp plug @w/2500 gals gel, 10 comp plug @w/2	eted operations. (Clearly state all pertinent details, rk). SEE RULE 1103. For Multiple Completions: osi for 30 mins. Ok. @ 5080-5280 w/ 1 SPF, 26 holes. s acid. Frac w/116,000 gals gel, 145,30 of 5040. Perf Middle Blinebry @ 4810-5016,000 gals gel, 146,156# 16/30 White per Blinebry @ 4540-4740 w/ 1 SPF, 2014,337# 16/30 White Sand, 31,548# 160-4242. Acidize w/ 3,000 gals acid. Frac Super LC. n out to PBTD 5510. RIH w/160jts 2-7/8	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 0.1# 16/30 White Sand, 35,296# 16/30 0.10 w/1 SPF, 26 holes. Acidize Sand, 35,250# 16/30 Super LC. Set 66 holes. Acidize w/2,500 gals acid. /30 Super LC. Set comp plug @ c w/ 101,000 gals gel, 111,793# 16/30	
13. Describe proposed or complete of starting any proposed wo or recompletion.  7/9/10 Test casing to 3500 proposed work of the starting any proposed work of starting and	eted operations. (Clearly state all pertinent details, rk). SEE RULE 1103. For Multiple Completions: osi for 30 mins. Ok. @ 5080-5280 w/ 1 SPF, 26 holes. s acid. Frac w/116,000 gals gel, 145,30 to 5040. Perf Middle Blinebry @ 4810-5016,000 gals gel, 146,156# 16/30 White per Blinebry @ 4540-4740 w/ 1 SPF, 214,337# 16/30 White Sand, 31,548# 160-4242. Acidize w/ 3,000 gals acid. Frace Super LC. In out to PBTD 5510. RIH w/160jts 2-7/80 "x24" pump. Hang on well.	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 0.1# 16/30 White Sand, 35,296# 16/30 0.10 w/1 SPF, 26 holes. Acidize Sand, 35,250# 16/30 Super LC. Set 66 holes. Acidize w/2,500 gals acid. /30 Super LC. Set comp plug @ c w/ 101,000 gals gel, 111,793# 16/30 8" J55 6.5# tbg, SN @ 5058.	
of starting any proposed wood or recompletion.  7/9/10 Test casing to 3500 proposed wood or recompletion.  7/12/10 Perf Lower Blinebry 7/13/10 Acidize w/2,500 gals. Super LC. Set comp plug @w/2500 gals acid. Frac w/ 10 comp plug @ 4780. Perf Up Frac w/ 116,000 gals gel, 144272. Perf Paddock @ 3976 White Sand, 17,437# 16/30 7/22/10 Drill out plugs. Clea 7/26/10 RIH w/ 2-1/2"x2-1/4	eted operations. (Clearly state all pertinent details, rk). SEE RULE 1103. For Multiple Completions: osi for 30 mins. Ok. @ 5080-5280 w/ 1 SPF, 26 holes. s acid. Frac w/116,000 gals gel, 145,30 of 5040. Perf Middle Blinebry @ 4810-5016,000 gals gel, 146,156# 16/30 White per Blinebry @ 4540-4740 w/ 1 SPF, 2014,337# 16/30 White Sand, 31,548# 160-4242. Acidize w/ 3,000 gals acid. Frac Super LC. n out to PBTD 5510. RIH w/160jts 2-7/8	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 0.1# 16/30 White Sand, 35,296# 16/30 0.10 w/1 SPF, 26 holes. Acidize Sand, 35,250# 16/30 Super LC. Set 66 holes. Acidize w/2,500 gals acid. /30 Super LC. Set comp plug @ c w/ 101,000 gals gel, 111,793# 16/30	
13. Describe proposed or complete of starting any proposed wo or recompletion.  7/9/10 Test casing to 3500 proposed work of the starting any proposed work of starting and	eted operations. (Clearly state all pertinent details, rk). SEE RULE 1103. For Multiple Completions: osi for 30 mins. Ok. @ 5080-5280 w/ 1 SPF, 26 holes. s acid. Frac w/116,000 gals gel, 145,30 to 5040. Perf Middle Blinebry @ 4810-5016,000 gals gel, 146,156# 16/30 White per Blinebry @ 4540-4740 w/ 1 SPF, 214,337# 16/30 White Sand, 31,548# 160-4242. Acidize w/ 3,000 gals acid. Frace Super LC. In out to PBTD 5510. RIH w/160jts 2-7/80 "x24" pump. Hang on well.	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 0.1# 16/30 White Sand, 35,296# 16/30 0.10 w/1 SPF, 26 holes. Acidize Sand, 35,250# 16/30 Super LC. Set 66 holes. Acidize w/2,500 gals acid. /30 Super LC. Set comp plug @ c w/ 101,000 gals gel, 111,793# 16/30 8" J55 6.5# tbg, SN @ 5058.	
of starting any proposed wo or recompletion.  7/9/10 Test casing to 3500 p  7/12/10 Perf Lower Blinebry  7/13/10 Acidize w/2,500 gals  Super LC. Set comp plug @  w/2500 gals acid. Frac w/ 12  comp plug @ 4780. Perf Up  Frac w/ 116,000 gals gel, 14  4272. Perf Paddock @ 3976  White Sand, 17,437# 16/30  7/22/10 Drill out plugs. Clea  7/26/10 RIH w/ 2-1/2"x2-1/4  Spud Date:	eted operations. (Clearly state all pertinent details, rk). SEE RULE 1103. For Multiple Completions: osi for 30 mins. Ok. @ 5080-5280 w/ 1 SPF, 26 holes. s acid. Frac w/116,000 gals gel, 145,30 to 5040. Perf Middle Blinebry @ 4810-5016,000 gals gel, 146,156# 16/30 White per Blinebry @ 4540-4740 w/ 1 SPF, 214,337# 16/30 White Sand, 31,548# 160-4242. Acidize w/ 3,000 gals acid. Frace Super LC. In out to PBTD 5510. RIH w/160jts 2-7/80 "x24" pump. Hang on well.	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 0.1# 16/30 White Sand, 35,296# 16/30 0.10 w/1 SPF, 26 holes. Acidize Sand, 35,250# 16/30 Super LC. Set 66 holes. Acidize w/2,500 gals acid. /30 Super LC. Set comp plug @ c w/ 101,000 gals gel, 111,793# 16/30 8" J55 6.5# tbg, SN @ 5058.	
of starting any proposed wo or recompletion.  7/9/10 Test casing to 3500 p  7/12/10 Perf Lower Blinebry  7/13/10 Acidize w/2,500 gals  Super LC. Set comp plug @  w/2500 gals acid. Frac w/ 12  comp plug @ 4780. Perf Up  Frac w/ 116,000 gals gel, 14  4272. Perf Paddock @ 3976  White Sand, 17,437# 16/30  7/22/10 Drill out plugs. Clea  7/26/10 RIH w/ 2-1/2"x2-1/4  Spud Date:	eted operations. (Clearly state all pertinent details, rk). SEE RULE 1103. For Multiple Completions: osi for 30 mins. Ok. @ 5080-5280 w/ 1 SPF, 26 holes. s acid. Frac w/116,000 gals gel, 145,30 g 5040. Perf Middle Blinebry @ 4810-5016,000 gals gel, 146,156# 16/30 White per Blinebry @ 4540-4740 w/ 1 SPF, 214,337# 16/30 White Sand, 31,548# 166-4242. Acidize w/ 3,000 gals acid. Frac Super LC. n out to PBTD 5510. RIH w/160jts 2-7/8 "x24" pump. Hang on well.	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 0.1# 16/30 White Sand, 35,296# 16/30 0.10 w/1 SPF, 26 holes. Acidize Sand, 35,250# 16/30 Super LC. Set 66 holes. Acidize w/2,500 gals acid. /30 Super LC. Set comp plug @ c w/ 101,000 gals gel, 111,793# 16/30 8" J55 6.5# tbg, SN @ 5058.	
13. Describe proposed or completion. 7/9/10 Test casing to 3500 p 7/12/10 Perf Lower Blinebry 7/13/10 Acidize w/2,500 gals Super LC. Set comp plug @ w/2500 gals acid. Frac w/ 1 comp plug @ 4780. Perf Up Frac w/ 116,000 gals gel, 14 4272. Perf Paddock @ 3976 White Sand, 17,437# 16/30 7/22/10 Drill out plugs. Clea 7/26/10 RIH w/ 2-1/2"x2-1/4 Spud Date:  6/24/10	eted operations. (Clearly state all pertinent details, rk). SEE RULE 1103. For Multiple Completions: osi for 30 mins. Ok.  © 5080-5280 w/ 1 SPF, 26 holes. s acid. Frac w/116,000 gals gel, 145,30 to 5040. Perf Middle Blinebry @ 4810-5016,000 gals gel, 146,156# 16/30 White per Blinebry @ 4540-4740 w/ 1 SPF, 2014,337# 16/30 White Sand, 31,548# 16/30 White Sand, 31,548# 16/30 White Sand Super LC. In out to PBTD 5510. RIH w/160jts 2-7/80 "x24" pump. Hang on well.  Rig Release Date:	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 0.1# 16/30 White Sand, 35,296# 16/30 0.10 w/1 SPF, 26 holes. Acidize Sand, 35,250# 16/30 Super LC. Set 16 holes. Acidize w/2,500 gals acid. 1/30 Super LC. Set comp plug @ c w/ 101,000 gals gel, 111,793# 16/30 8" J55 6.5# tbg, SN @ 5058.	
13. Describe proposed or completion of starting any proposed wo or recompletion.  7/9/10 Test casing to 3500 proposed work of the starting any proposed work of starting and st	eted operations. (Clearly state all pertinent details, rk). SEE RULE 1103. For Multiple Completions: osi for 30 mins. Ok.  © 5080-5280 w/ 1 SPF, 26 holes. s acid. Frac w/116,000 gals gel, 145,30 to 5040. Perf Middle Blinebry @ 4810-5016,000 gals gel, 146,156# 16/30 White per Blinebry @ 4540-4740 w/ 1 SPF, 204,337# 16/30 White Sand, 31,548# 16/30 White Sand, 31,548# 16/30 White Super LC. In out to PBTD 5510. RIH w/160jts 2-7/80 "x24" pump. Hang on well.  Rig Release Date:    Rig Release Date:	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 0.1# 16/30 White Sand, 35,296# 16/30 0.10 w/1 SPF, 26 holes. Acidize Sand, 35,250# 16/30 Super LC. Set 16 holes. Acidize w/2,500 gals acid. 1/30 Super LC. Set comp plug @ c w/ 101,000 gals gel, 111,793# 16/30 8" J55 6.5# tbg, SN @ 5058.	
13. Describe proposed or completion of starting any proposed wo or recompletion.  7/9/10 Test casing to 3500 proposed work of the starting any proposed work of starting and starting an	eted operations. (Clearly state all pertinent details, rk). SEE RULE 1103. For Multiple Completions: osi for 30 mins. Ok.  © 5080-5280 w/ 1 SPF, 26 holes. s acid. Frac w/116,000 gals gel, 145,30 to 5040. Perf Middle Blinebry @ 4810-5016,000 gals gel, 146,156# 16/30 White per Blinebry @ 4540-4740 w/ 1 SPF, 204,337# 16/30 White Sand, 31,548# 16/30 White Sand, 31,548# 16/30 White Super LC. In out to PBTD 5510. RIH w/160jts 2-7/80 "x24" pump. Hang on well.  Rig Release Date:    Rig Release Date:	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 0.1# 16/30 White Sand, 35,296# 16/30 0.10 w/1 SPF, 26 holes. Acidize Sand, 35,250# 16/30 Super LC. Set 16 holes. Acidize w/2,500 gals acid. 1/30 Super LC. Set comp plug @ c w/ 101,000 gals gel, 111,793# 16/30 8" J55 6.5# tbg, SN @ 5058.	
13. Describe proposed or completion of starting any proposed wo or recompletion.  7/9/10 Test casing to 3500 proposed work of the starting any proposed work of starting and st	eted operations. (Clearly state all pertinent details, rk). SEE RULE 1103. For Multiple Completions: osi for 30 mins. Ok.  © 5080-5280 w/ 1 SPF, 26 holes. s acid. Frac w/116,000 gals gel, 145,30 to 5040. Perf Middle Blinebry @ 4810-5016,000 gals gel, 146,156# 16/30 White per Blinebry @ 4540-4740 w/ 1 SPF, 2014,337# 16/30 White Sand, 31,548# 16/30 White Sand, 31,548# 16/30 White Super LC. In out to PBTD 5510. RIH w/160jts 2-7/80 "x24" pump. Hang on well.  Rig Release Date:  TITLE Agent for COG Stoon E-mail address:	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 0.1# 16/30 White Sand, 35,296# 16/30 0.10 w/1 SPF, 26 holes. Acidize Sand, 35,250# 16/30 Super LC. Set 16 holes. Acidize w/2,500 gals acid. 1/30 Super LC. Set comp plug @ c w/ 101,000 gals gel, 111,793# 16/30 8" J55 6.5# tbg, SN @ 5058.  7/1/10  cdge and belief.  DATE 7/12/10  resources.com PHONE: 432-686-3087	
13. Describe proposed or completion of starting any proposed wo or recompletion.  7/9/10 Test casing to 3500 proposed work of the starting any proposed work of starting and starting an	eted operations. (Clearly state all pertinent details, rk). SEE RULE 1103. For Multiple Completions: osi for 30 mins. Ok.  © 5080-5280 w/ 1 SPF, 26 holes. s acid. Frac w/116,000 gals gel, 145,30 to 5040. Perf Middle Blinebry @ 4810-5016,000 gals gel, 146,156# 16/30 White per Blinebry @ 4540-4740 w/ 1 SPF, 204,337# 16/30 White Sand, 31,548# 16/30 White Sand, 31,548# 16/30 White Super LC. In out to PBTD 5510. RIH w/160jts 2-7/80 "x24" pump. Hang on well.  Rig Release Date:    Rig Release Date:	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 0.1# 16/30 White Sand, 35,296# 16/30 0.10 w/1 SPF, 26 holes. Acidize Sand, 35,250# 16/30 Super LC. Set 16 holes. Acidize w/2,500 gals acid. 1/30 Super LC. Set comp plug @ c w/ 101,000 gals gel, 111,793# 16/30 8" J55 6.5# tbg, SN @ 5058.  7/1/10  cdge and belief.  DATE 7/12/10  resources.com PHONE: 432-686-3087	