

Operator
Well
Unit
API #

N. Dale Nichols

Lewis Neff #4

0 Section 32 Township 7 Range 27

30-005-00224

TOPS

T Salt 400?

B Salt 390?

Queen 1140

Grayburg -

San Andres 1346

2-60' Surface Plug

7" @ 293'
25 SXS
8 3/4" hole

2 shoe & salt plug to
243' - 400' tag

← 990' TAG

1586'

TOC @ 50%

← 1900' - TAG

4 1/2" @ 1908'
50 SXS
6 1/4" hole

OH
1960'

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10% brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.