

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each
- Install dry hole marker as per Rule 202.B.2
- Plugs are to be set from point indicated up.
- Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- Shoe and stub plugs will be 50' above and below
- Surface plug will be from 0' 60'
- Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no
- Plugs to be tagged will be indicated.