

Operator N. Dale Nichols
 Well STATE 'A' #3
 Unit A Section 7 Township 8 Range 22
 API # 30-005-00233

TOPS

Salted	470?
B Salt	1000?
Gates	
Green	900
Grayburg	1210
San Andres	1367

← 60' Surface Plug

Pulled

← 470' - Tag

10 3/4 @ 415
 Pulled
 12" hole

← 1100' Tag

← 1900' - Tag

1943
 1959
 1976

Pbs

5 1/2" @ 1997
 630 SVS.
 CIR

OH
 2190

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.