

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE	1	
FILE	1	✓
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

MAR 10 1971

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>	
5. State Oil & Gas Lease No. B-8385-1	
7. Unit Agreement Name -	
8. Farm or Lease Name New Mexico 'AM' State	
9. Well No. NCT-3 3	
10. Field and Pool, or Wildcat Coyote Queen	
12. County Chaves	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER -
2. Name of Operator TEXACO Inc.
3. Address of Operator P.O. BOX 728 - HOBBS, NEW MEXICO 88240
4. Location of Well UNIT LETTER L , 1650 FEET FROM THE South LINE AND 660 FEET FROM THE West LINE, SECTION 11 TOWNSHIP 11-S RANGE 27-E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3704' GR

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

The following work on subject well has been completed:

1. Ran 2" tubing to TD.
2. Displaced water with mud in 4-1/2" casing.
3. Spot 15 sx cement plug from 1020' to 865' over perforations 940'-983'.
4. Pulled tubing.
5. Spot 10 sx cement plug at surface.
6. Cut off well head and installed 4" Dry Hole Marker extending 4' above ground level.
7. Clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE **Asst. Dist. Superintendent** DATE **March 9, 1971**

APPROVED BY [Signature] TITLE **OIL AND GAS INSPECTOR** DATE **JUN 10 1971**

CONDITIONS OF APPROVAL, IF ANY: