

TOPS

LGES	115
T Rivers	150
Queen	520
Pennese	822

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of **all casing string(s)** in the correct footage or sacks required, if **no cement exists**.
- * Plugs to be tagged will be indicated.

889' ← Plug 839' Top
948' =

4 1/2" @ 954
100 sxs

2