

August 6, 1991

Day #59, PTD 8281' vis 46, wl 12, wt 9.7. Trip 11 hrs, wait on tool 2 1/4 hrs, fishing wireline 7 hrs, wait on wireline 2 hrs, make up OS 1/2 hr, work with OS 1 1/4 hrs.

- (1) Ran two prong wireline spear to 1054', no recovery, to 1116', no recovery, ran wireline centered spear to 1736', rotate down in wireline. POH w/ 20,000# drag. Recover 100% wireline. Left rope socket CCL and shearing tool (tube 1 11/16" OD 14' long) TIH OS w/ 3 5/8" grappel kutlip guide shoe. Work with fish. POH. No recovery. No impression on grappel. TIH OS with 3 5/8" grappel kutrite guide shoe. Work with fish. POH. No recovery. Cut mark on grappel. TIH OS with 3 1/2" grappel kutrite guide shoe.

August 7, 1991

Day #60, PTD 8281', oper circulating. Vis 45, wl 10, wt 9.6. Circulate 6 3/4 hrs, trip 10 hrs, fish 1 3/4 hrs, WO order 1 3/4 hrs, cut drilling line 3/4 hr and wash on top of fish 2 1/2 hrs, lay down OS and pick up 7 7/8" bit 1/4 hr.

- (1) Finish TIH, wash to fish, catch fish and work 80,000# over string wt. Pulled free. POH. Recovered second OS.
- (2) TIH with 7 7/8" OS 6" grappel. Texas pattern guide shoe. Unable to wash to fish. POH.
- (3) TIH 7 7/8" bit, clean out top of fish. Circulate. Condition hole. Stop high vis slug on top of fish. POH.

August 8, 1991	Waiting on orders.
August 9, 1991	Waiting on orders.
August 10, 1991	Waiting on orders.
August 11, 1991	Waiting on orders.
August 12, 1991	Waiting on orders.
August 13, 1991	Waiting on orders.
August 14, 1991	Waiting on orders.
August 15, 1991	Waiting on orders.
August 16, 1991	Waiting on orders.
August 17, 1991	Waiting on orders.
August 18, 1991	Waiting on orders.
August 19, 1991	Waiting on orders.
August 20, 1991	Waiting on orders.