

2-20-96

Pull up hole to 4650' + spot 30 ss.

Pull up hole to 3200' + spot 30 ss.

Pull up hole to 1950' + spot 30 ss. + tag.

WOC + tagged plug @ 1838'.

Pull up hole to 150' + fill to surface with cement.

Place P+A Marker.

Clean + level location.