

Operator MEW Enterprise
 Well Crandell Phillips #1
 Unit L Section 34 Township 6 Range 26
 API # 30-0 DS-1052

TOPS

Queen 150'
San Andre 680'
Slaughter
(San Andres @) 920'

← 60' Surface Plug.

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

← 155' Shoe Plug. TAG

Cal. Tos. 972'. 4 1/2" csg.

← 1048' TAG

+ Perfs - 1108'-68'

11" Hole.
 Cal. To Circ?

4 1/2" @ 1211'
 150 SXS CMT.

6 3/4" hole