

COMPANY <i>Southeastern Petroleum Inc.</i>		PROPERTY NAME <i>Sturgeon</i>	WELL NO. <i>2</i>
DATE <i>20.05.1967</i>	LOCATION (ULSTR) <i>UT F - 33-6-26</i>	FOOTAGE <i>8369 FT. 4 1/2" x 5 1/2"</i>	
API NO. <i>20.05.1967</i>		POOL <i>Lima San Andres</i>	
<i>1. Spot a 20 ft plug & tag</i> <i>2. Perforate 4 1/2" x 160'</i> <i>3. Circulate cement to surface behind 4 1/2" & leave 4 1/2" csg full cement.</i> <i>4. Set P&H marker</i> <i>5. Clean & level location, cut anchors.</i> <i>6. Place mud between plugs</i>		<i>After</i>	
CASING RECORD: <i>8 5/8" x 107' 50 SX 11" hole</i> <i>4 1/2" x 1070' 50 SX 6 3/4" hole</i> <i>Perforations 104'</i> <i>TOC @ 593'</i> <i>San Andres 512'</i>		<i>20 ft</i> <i>160 ft</i> <i>512 ft</i>	