

COMPANY

Southern Petroleum Inc.

PROPERTY NAME

Sturgen

WELL NO.

2

DATE

LOCATION (ULSTR)

U+ F. 33-6-26

FOOTAGE

2329 FWL + 2310 ENL

API NO.

30-005-10071

POOL

Linda San Andres

1. Spots 50-54 plugs for wire & tag
2. Perforate 4 1/2' @ 160'
3. Circulate cement to surface behind 4 1/2' & leave 4 1/2' csg. full cement.
4. Set P&H marker
5. Clean & level location, cut anchors.
6. Place mud between plugs

CASING RECORD:

8 5/8" @ 107' = 50 SX 11" hole

4 1/2" @ 1070' 50 SX 6 3/4" hole

Perforations 1004'

TOC @ 593'

San Andres 518'

After

8 5/8" 107'

TOC 593'

Perf = 1004'

4 1/2" 1070'