

Operator  
Well  
Unit  
API #

N. Dale Nichols

Standard State # 13

B Section S Township 8 Range 27

30-005-10429

TOPS

|            |      |
|------------|------|
| Gares      | 310  |
| Queen      | 870  |
| Pearce     | 1050 |
| Grayburg   | 1215 |
| San Andres | 1350 |

← 60' Surface Plug

8 3/8" @ 153

100 SXS

1 1/4 hole  
Calc. Circ

← Shoe Plug 103'-203'  
TAG

← 310'

1033' ——— TOC @ 50%

← 1900' — TAG

1938' - 1960'

Perls

4 1/2" @ 1978'

325 SXS

7 7/8 hole

- \* Contact OCD 24 hrs. prior to any work done.
- \* Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- \* Install dry hole marker as per Rule 202.B.2
- \* Plugs are to be set from point indicated up.
- \* Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- \* Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- \* Surface plug will be from 0' - 60'
- \* Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- \* Plugs to be tagged will be indicated.