Operator Well Unit API # 3	N. Dale Michals Standard Sinte IV <u>G</u> Section <u>S</u> /Twnship 30-0 <u>c5</u> - <u>10513</u>	8_	Range <u>2</u>	Lygres 200
	K- Surface Plug			Grayburg 1 1195 Sen Andres 21350
1		*	Salt gel mud co	4 hrs. prior to any work done. onsisting of 10# brine with 25#
		* *	plug. Install dry hole Plugs are to be Plugs must not of cement, which	marker as per Rule 202.B.2 set from point indicated up. be less than 100' or 25 Sacks chever is greater, unless
85/8'@ 150' CIFC 200'	<- Shoz Plug 100'-200' Tag 	* * *	shoe or stub ar Surface plug wi Where plugs ar	plugs will be 50' above and below
	- Phy 1890' Tag	*	in the correct for cement exists.	otage or sacks required, if no
1940', 1942 41/2" (20 1971 350 393.				·

_