

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. <u>30-005-10557</u>
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name <u>State E 92</u>
8. Well No. <u>17</u>
9. Pool name or Wildcat

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator <u>Mountain States Petroleum Corp.</u>
3. Address of Operator <u>Post Office Box 1936 Roswell, New Mexico 88202</u>

4. Well Location Unit Letter <u>K</u> : <u>2310</u> Feet From The <u>West</u> Line and <u>2310</u> Feet From The <u>South</u> Line Section <u>26</u> Township <u>10S</u> Range <u>26E</u> NMPM <u>Chaves</u> County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
--

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Post ID-2
5-29-98
PFF

MIRU. Pull all rods, Pump & Tubing.
RIW with tubing, open ended to bottom of perfs.
Pump 40 sks cement, pull 1/2 tubing.
Pump cement until circulated -pull tubing and fill void.
Set dry hole marker and level and clean location.

This well has been plugged & Abandoned.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.	
SIGNATURE <u>Ruby Wickersham</u>	TITLE <u>Agent</u> DATE <u>05/01/98</u>
TYPE OR PRINT NAME	TELEPHONE NO.

(This space for State Use)	
APPROVED BY <u>[Signature]</u>	TITLE <u>Std Rep</u> DATE <u>7-26-99</u>
CONDITIONS OF APPROVAL, IF ANY:	